Original		Replacement	
I/⏻	Power	⏻	Power
TV I/⏻	Tv Power	SHIFT + ⏻	Shift + Power
ONE-TOUCH PLAY	One Touch Play	FAV 2. P/C	P/C / FAV
THEATRE	Theatre	EPG 1. -/--	-/-- / EPG
DVD/CD	1	1	1
FM	2	2 ABC	2
USB	3	3 DEF	3
TV	4	4 GHI	4
AUDIO IN	5	5 JKL	5
FUNCTION	6	6 MNO	6
TIME/ TEXT	7	7 PQRS	7
SOUND MODE	8	8 TUV	8
SYSTEM MENU	9	9 WXYZ	9
SUBTITLE D.TUNING	0	0	0
DVD/CD	DVD/CD	D	Blue (D)
FM	FM	B	Green (B)
USB	USB	SRC	SRC

Original		Replacement	
TV	TV	C	Yellow (C)
AUDIO IN	Audio In	A	Red (A)
FUNCTION	Function	WIDE	WIDE
TIME/ TEXT	Time / Text	TEXT	TEXT
SOUND MODE	Sound Mode	V-FOR	V-FOR
SYSTEM MENU	System Menu	MENU	MENU
CLEAR AUDIO	Audio	🔊?	Audio
CLEAR AUDIO	Clear	EXIT	EXIT
SUBTITLE D.TUNING	Subtitle / D. Tuning	▭	Subt.
TV INPUT ANGLE MEM SEL	Angle / Mem Sel	OPT+	OPT+
TV INPUT ANGLE MEM SEL	TV Input	TV/R	TV/R
DVD TOP MENU	DVD Top Menu	VOD	VOD
DVD MENU	DVD Menu	MEDIA	MEDIA
VOLUME +	Volume +	+ VOL	VOL +
−	Volume -	VOL −	VOL -
MUTING	Muting	🔇	MUTE
DISPLAY	Display	INFO	INFO

Original		Replacement	
RETURN	Return	BACK	BACK
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	OK	OK	OK
PRESET–	I<< / Preset -		First
PRESET+	>>I / Preset +		Last
	Pause		Pause
	Play		Play
	Stop		Stop
TUNING–	<< / Tuning - /		Rewind
TUNING+	>> / Tuning + /		Fast Forward

Original	Replacement