Mandis shop

Sony RMF-TX221ES

Original		Replacement	
	Power		Power
	Input	TIMER AV	AV
DIGITAL/ ANALOG	Digital/Analog	SETTINGS OPT	Options
TV/ RADIO	Tv/Radio	SEARCH TV/R	TV/R
EXIT	Exit	CLEAR EXIT	Exit
EXT.BOX MENU	Ext. Box Menu	TOP MENU MENU	Menu
1	1	1	1
2 abc	2	2	2
3 def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6 mno	6	6	6
7 pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0	0	0	0
	[i+]/[?]	DISPLAY INFO	Info

Original		Replacement	
	[≡]	REPEAT TEXT	Text
Google Play	Google Play	APP MEDIA	Media
NETFLIX	Netflix	SHIFT + HOME SMART	Shift + Smart
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
ACTION MENU	Action Menu	E-MANUAL D.MENU	D. Menu
GUIDE	Guide	-/-- GUIDE	Guide
APPS	APPS	SHIFT + APP MEDIA	Shift + Media
BACK	Back	RETURN BACK	Back
TV	TV	ECO 3D	3D
	Up		Up
HOME	Home	HOME SMART	Smart
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	OK	OK	Ok
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
PROG +	Prog +	+ CH	Ch +
	Prog -	CH −	Ch -
	Recall	FAV PRE-CH	Pre Ch
AUDIO	Audio	SOUND DUAL	Dual
	<<	<<	<<
	Play	PLAY MODE	Play
	>>	>>	>>
	I <<	I <<	I <<
	Pause	II	Pause
	>>I	>>I	>>I
REC	Rec	REC MODE	Rec
	Stop		Stop
TITLE LIST	Title List	DISC NAV LIST	List

Original		Replacement	
	[. . .]	AD SUBT	Subt
HELP	Help	PICTURE FORMAT	Format