Mandis shop

Sony RMSR5

Original		Replacement	
DISC SKIP	Disc Skip	Prime Video / RANDOM	Blue / Prime Video / Random
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I/⏻	Power		Power
CD	CD Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
TUNER/BAND	Tuner/Band	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
DECK A	Deck A Play	NETFLIX / SEARCH	Red / Netflix / Search
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
DECK B	Deck B Play	APP / REPEAT	Green / APP / Repeat
CHECK	Check	MEDIA / DISPLAY	Display / Media
CLEAR	Clear	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
MD	MD Play	SHIFT + SLOW	Shift + Play /
	Pause MD	SHIFT + STEP-FREEZE	Shift + Pause / Step / Freeze

Original		Replacement	
	Stop MD	SHIFT + HOLD	Shift + Stop /
LOOP	Loop	LIST SMART	Smart / List
FLASH	Flash	ANGLE INFO	Info / Angle
FUNCTION	Function	HOME MENU	Menu / Home
FILE SELECT	Up		Up
VOL	Vol +	VOL +	Vol +
ON/OFF	On / Off	OK	OK
	Down		Down
	Vol -	VOL -	Vol -

https://al-remotecontrols.com/en/Sony/13851-309-replacement-remote-control-for-Sony-RM-SR5-147527111.html