Mandis shop

RM-D391

Original		Replacement	
REPEAT	Repeat	REPEAT TEXT	Text
FADER	Fader	SEARCH TV/R	TV/R
CONTINUE	Continue	SOUND DUAL	Dual
SHUFFLE	Shuffle	AD SUBT	Subt
PGM	PGM	SETTINGS OPT	Options
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
>10	>10	-/-- GUIDE	Guide
▶	Play	PLAY MODE ▶	Play

Original		Replacement	
⏸	Pause	⏸	Pause
■	Stop	■	Stop
⏮ AMS	I << AMS	⏮	I <<
AMS ⏭	AMS >>I	⏭	>>I
◀◀	<<	◀◀	<<
▶▶	>>	▶▶	>>

https://al-remotecontrols.nl/en/Sony/1895825-replacement-remote-control-for-Sony-RM-D391.html