Original		Replacement	
	Power		Power
	HDMI / Control		Smart
	Rec		Rec
	Stop		Stop
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
	Red/ Zoom/ ↑↓		Red
	Green/ Repeat / ↓		Green
	Yellow/ Root		Yellow
	Blue/ Title		Blue
	Screen		Format
	Lang		Dual
	Subtitle		Subt

Original		Replacement	
	Internet / PIP		Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TEXT	Text	TEXT	Text
INFO	Info	INFO	Info
SOURCE	Source	AV	AV
OK	OK	OK	Ok
	Up		Up
	Down		Down

Original		Replacement		Original		Replacement	
	Right		Right				
	Left		Left				
P+	P+	+ CH	Ch +				
P-	P-	CH −	Ch -				
V+	Vol +	+ VOL	Vol +				
V-	Vol -	VOL −	Vol -				
MENU	Menu	TOP MENU MENU	Menu				
	Mute	MUTE	Mute				
RETURN	Return	RETURN BACK	Back				
SWAP	Swap	FAV PRE-CH	Pre Ch				
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch				
EPG	EPG	-/-- GUIDE	Guide				
SLEEP	Sleep	PROG SLEEP	Sleep				
SEARCH MODE	Search Mode	SHIFT + TIMER AV	Shift + AV				
	Ball / Angle	SETTINGS OPT	Options				
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info				
PRESETS	Presets	SEARCH TV/R	TV/R				