Original		Replacement	
	Power		Power
TRK +	TRK+	SHIFT +	Shift + Right
TRK -	TRK-	SHIFT +	Shift + Left
PREF.	Red/ Pref.	A	Red
SHOWVIEW	Green/ Showvie	B	Green
INFO	Yellow/ Info	C	Yellow
TV	Blue/ Tv Time	D	Blue
TEXT	Violet/ Text	REPEAT TEXT	Text
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
VPS	Up/ VPS		Up
GO TO 0000	Down/ Goto		Down
	Right/ >>I		Right
	Left/ I<<		Left
OK	OK	OK	Ok
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -

Original		Replacement	
	Mute	MUTE	Mute
PR+	PR+	CH +	Ch +
PR-	PR-	CH -	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/--	0/ - -	0	0
AV	AV	TIMER AV	AV
F.FWD	>>/ F. FWD	>>	>>
0000	000	APP MEDIA	Media
REW.	<</ REW	<<	<<

Original		Replacement		Original		Replacement	
MONITOR	Monitor	ZOOM	Eject				
SP/LP	SP/LP	PROG SLEEP	Sleep				
STOP	Stop		Stop				
PLAY	Play	PLAY MODE	Play				
PAUSE	Pause		Pause				
REC.	Rec	REC MODE	Rec				