# Mandis shop

RCT200DV

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| OPEN / CLOSE | Open/Close | ZOOM | Eject |
| | Mute | MUTE | Mute |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| AUDIO | Audio | SOUND DUAL | Dual |
| | (.....) | AD SUBT | Subt |
| | Movie | HOME SMART | Smart |
| MENU | Menu | TOP MENU MENU | Menu |

| Original | | Replacement | |
|---|---|---|---|
| TITLE | Title | APP MEDIA | Media |
| | (¨¨¨¨) | SEARCH TV/R | TV/R |
| EXIT | Exit | CLEAR EXIT | Exit |
| | >> | | >> |
| | << | | << |
| OK | Play | PLAY MODE | Play |
| OK | OK | OK | Ok |
| | > | | Right |
| | < | | Left |
| | Up | | Up |
| | Down | | Down |
| | >>I | | >>I |
| | I << | | I << |
| | Stop | | Stop |
| REPEAT | Repeat | REPEAT TEXT | Text |
| | Pause | | Pause |
| INDEX | Index | DISC NAV LIST | List |

https://al-remotecontrols.nl/en/10290-124-replacement-remote-control-for-RCT200DV-35150.htm