| Original | | Replacement | |
|---|---|---|---|
| STANDBY/ON | Standby / On | | Power |
| STB | STB | SHIFT + CD - STB 3 | Shift + 3 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| AUX | AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| TV | TV | SHIFT + TV 1 | Shift + 1 |
| VOL MODE | Vol Mode | LIST SMART | Smart / List |
| AUTO SETUP | Auto Setup | OPT-TOOLS SETUP | Setup / OPT / |
| INPUTMODE | Input Mode | RDS AV INPUT | AV / Input / RDS |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| 5BEAM 1 | 1 / 5BEAM | TV 1 | 1 |
| ST+3BEAM 2 | 2 / ST + 3BEAM | DVD 2 | 2 |
| 3BEAM 3 | 3 / 3BEAM | CD - STB 3 | 3 |
| STEREO 4 | 4 / Stereo | VIDEO 4 | 4 |
| MY BEAM 5 | 5 / My Beam | TAPE 5 | 5 |
| SURROUND 6 | 6 / Surround | SURROUND | Eject / Surround |
| SURROUND 6 | 6 / Surround | TUNER 6 | 6 |
| MUSIC 7 | 7 / Music | AUX - HDD 7 | 7 |

| Original | | Replacement | |
|---|---|---|---|
| MOVIE 8 | 8 / Movie | USB 8 | 8 |
| SPORTS 9 | 9 / Sports | BLUETOOTH 9 | 9 |
| OFF 0 | 0 / Off | HDMI - SAT 0 | 0 |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| (•) | (•) | LANG I/II AUDIO | Audio / Lang I/II |
| CH LEVEL | CH Level | MEDIA DISPLAY | Display / Media |
| | Up | | Up |
| MENU | Menu | HOME MENU | Menu / Home |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| TEST | Test | GOTO TEXT | Text / Goto |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| VOLUME + | Volume + | VOL + | Vol + |
| VOLUME - | Volume - | VOL - | Vol - |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Replacement | |
|---|---|---|---|
| STANDBY/ON | Power | | Power |
| INPUT1 | Input 1 | LIST SMART | Smart / List |
| INPUT2 | Input 2 | MEDIA DISPLAY | Display / Media |
| 5BEAM 1 | 1 | TV 1 | 1 |
| ST+3BEAM 2 | 2 | DVD 2 | 2 |
| 3BEAM 3 | 3 | CD - STB 3 | 3 |
| STEREO 4 | 4 | VIDEO 4 | 4 |
| MY BEAM 5 | 5 | TAPE 5 | 5 |
| SURROUND 6 | 6 | TUNER 6 | 6 |
| MUSIC 7 | 7 | AUX - HDD 7 | 7 |
| MOVIE 8 | 8 | USB 8 | 8 |
| SPORTS 9 | 9 | BLUETOOTH 9 | 9 |
| OFF 0 | 0 | HDMI - SAT 0 | 0 |
| CH + | CH+ | CH PAGE + | CH+ / Page+ |
| TV VOL + | Tv Vol + | VOL + | Vol + |
| CH - | CH- | CH PAGE - | CH- / Page- |
| TV VOL - | Tv Vol - | VOL - | Vol - |

| Original | | Replacement | |
|---|---|---|---|
| TV INPUT | Tv Input | RDS AV INPUT | AV / Input / RDS |
| TV MUTE CODE SET | Tv Mute | DIMMER MUTE | Mute / Dimmer |
| POWER AV | Power AUX | SHIFT + | Shift + Power |
| 5BEAM 1 | 1 AUX | SHIFT + TV 1 | Shift + 1 |
| ST+3BEAM 2 | 2 AUX | SHIFT + DVD 2 | Shift + 2 |
| 3BEAM 3 | 3 AUX | SHIFT + CD - STB 3 | Shift + 3 |
| STEREO 4 | 4 AUX | SHIFT + VIDEO 4 | Shift + 4 |
| MY BEAM 5 | 5 AUX | SHIFT + TAPE 5 | Shift + 5 |
| SURROUND 6 | 6 AUX | SHIFT + TUNER 6 | Shift + 6 |
| MUSIC 7 | 7 AUX | SHIFT + AUX - HDD 7 | Shift + 7 |
| MOVIE 8 | 8 AUX | SHIFT + USB 8 | Shift + 8 |
| SPORTS 9 | 9 AUX | SHIFT + BLUETOOTH 9 | Shift + 9 |
| OFF 0 | 0 AUX | SHIFT + HDMI - SAT 0 | Shift + 0 |

| Original | | Replacement | |
|---|---|---|---|
| STANDBY/ON | Power | | Power |
| 5BEAM 1 | 1 | TV 1 | 1 |
| ST+3BEAM 2 | 2 | DVD 2 | 2 |
| 3BEAM 3 | 3 | CD-STB 3 | 3 |
| STEREO 4 | 4 | VIDEO 4 | 4 |
| MY BEAM 5 | 5 | TAPE 5 | 5 |
| SURROUND 6 | 6 | TUNER 6 | 6 |
| MUSIC 7 | 7 | AUX-HDD 7 | 7 |
| MOVIE 8 | 8 | USB 8 | 8 |
| SPORTS 9 | 9 | BLUETOOTH 9 | 9 |
| OFF 0 | 0 | HDMI-SAT 0 | 0 |
| +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| MENU | Menu | HOME MENU | Menu / Home |
| RETURN | Return | RETURN BACK | Back / Return |
| | << | TUNE- | << / Tune- |
| | Stop | HOLD | Stop / Hold |
| | >> | TUNE+ | >> / Tune+ |

| Original | | Replacement | |
|---|---|---|---|
| | I << | PRESET- | I << / Preset- |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | >>I | PRESET+ | >>I / Preset+ |
| | Play | SLOW | Play / Slow |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| STANDBY/ON | Power | | Power | | | | |
| 5BEAM 1 | 1 | TV 1 | 1 | | | | |
| ST+3BEAM 2 | 2 | DVD 2 | 2 | | | | |
| 3BEAM 3 | 3 | CD-STB 3 | 3 | | | | |
| STEREO 4 | 4 | VIDEO 4 | 4 | | | | |
| MY BEAM 5 | 5 | TAPE 5 | 5 | | | | |
| SURROUND 6 | 6 | TUNER 6 | 6 | | | | |
| MUSIC 7 | 7 | AUX-HDD 7 | 7 | | | | |
| MOVIE 8 | 8 | USB 8 | 8 | | | | |
| SPORTS 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| OFF 0 | 0 | HDMI-SAT 0 | 0 | | | | |
| << | << | TUNE- << | << / Tune- | | | | |
| Stop | Stop | HOLD Stop | Stop / Hold | | | | |
| >> | >> | TUNE+ >> | >> / Tune+ | | | | |
| Pause | Pause | STEP-FREEZE Pause | Pause / Step / Freeze | | | | |
| Play | Play | SLOW Play | Play / Slow | | | | |
| | | | | | | | |