Original		Rechange	
	Power		Power
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
M	Menu	HOME MENU	Menu / Home
P<P	P<P	LIST SMART	Smart / List
	Up		Up
	Left		Left
OK	Ok	OK	OK
	Right		Right
	Down		Down
AV	AV	RDS AV INPUT	AV / Input / RDS
TV/	Tv/R	PROGRAM TV/ RADIO	TV/Radio /
INFO i	Info	ANGLE INFO	Info / Angle
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II
+ V	Vol +	+ VOL	Vol +

Original		Rechange	
+ P	P+	+ CH PAGE	CH+ / Page+
V −	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
P −	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PP	PP	RETURN BACK	Back / Return
0	0	HDMI-SAT 0	0
-/-- EXIT	-/-- Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
-/-- EXIT	-/-- Exit	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--

Original		Rechange		Original	Rechange
	[≡] / Text	GOTO TEXT	Text / Goto		
	[≡o]	TUNE-	<< / Tune-		
	[≡+]	TUNE+	>> / Tune+		
	[≡x]	PRESET-	I << / Preset-		
	[. ≡] / [*]	PRESET+	>>I / Preset +		
WIDE	[≡♦] / [+] / Wide	FORMAT PICTURE	Picture / Format		
PC	[≡?] / PC	PC FAV MARKER	Fav / Marker / PC		
GUIDE	[≡i] / Guide	-/-- GUIDE EPG	Guide / EPG / -/--		