| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| TV/TXT PRO | PRO/ TV/ TXT | REPEAT TEXT | Text |
| CANCEL SLOW | Slow/ Cancel | ECO 3D | 3D |
| REVEAL REP | Rep/ Reveal | SEARCH TV/R | TV/ R |
| SOURCE | Source | TIMER AV | AV |
| HOLD | <</ Hold | << | << |
| SIZE | >>/ Size | >> | >> |
| SUBPAGE | I <</ Subpage | I<< | I << |
| INDEX | >>I / Index | >>I | >>I |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |

| Original | | Rechange | |
|---|---|---|---|
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| VOL+ | Vol + | + VOL | Vol + |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| VOL- | Vol - | VOL – | Vol - |
| CH+ | CH+ | + CH | Ch + |
| | Recall | RETURN BACK | Back |
| CH- | CH- | CH – | Ch - |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |
| OK | OK | OK | Ok |
| MENU | Menu | TOP MENU MENU | Menu |
| CH/LIST SET | Set / CH/ List | HOME SMART | Smart |
| EXIT | Exit | CLEAR EXIT | Exit |
| DISPLAY | Display | DISPLAY INFO | Info |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| NICAM/A2 | Nicam/A2 | SETTINGS OPT | Options | | |
| MUTE | Mute | MUTE | Mute | | |
| PICTURE | Picture | PICTURE FORMAT | Format | | |
| SOUND | Sound | SOUND DUAL | Dual | | |
| SLEEP | Sleep | PROG SLEEP | Sleep | | |
| SUBTITLE | Subtitle | AD SUBT | Subt | | |
| EPG LAN | LAN/EPG | -/-- GUIDE | Guide | | |
| II | Pause | II | Pause | | |
| ▶ | Play | PLAY MODE ▶ | Play | | |
| RECORD ⏏ | Rec | REC MODE ● | Rec | | |
| STOP ■ | Stop | ■ | Stop | | |
| RECORD ⏏ | Open/Close | ZOOM ⏏ | Eject | | |
| LIST D-MENU | D-Menu/List | E-MANUAL D.MENU | D. Menu | | |
| | Red | A | Red | | |
| | Green | B | Green | | |
| | Yellow | C | Yellow | | |
| SCREEN | Blue/Screen | D | Blue | | |