Original		Rechange	
	Power		Power
T.OPT	T. Opt.	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
TV/RAD	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TV/PC	TV/PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
PIP/* AD	PIP/* / AD	LANG I/II AUDIO	Audio / Lang I/II
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Rechange	
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Mute	DIMMER MUTE	Mute / Dimmer
P PAGE	P+	+ CH PAGE	CH+ / Page+
P PAGE	P-	CH PAGE −	CH- / Page-
TEXT	Text	GOTO TEXT	Text / Goto
	Home	HOME MENU	Menu / Home
BACK	Back	RETURN BACK	Back / Return
T.OPT	T. Opt.	FORMAT PICTURE	Picture / Format
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
INFO	Info	ANGLE INFO	Info / Angle
LIST	List	LIST SMART	Smart / List
	☼	OPT-TOOLS SETUP	Setup / OPT /
OK	OK	OK	OK

Original		Rechange		Original	Rechange
Q.VIEW	Q. View	MEDIA DISPLAY	Display / Media		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Green/Games	APP REPEAT	Green / APP / Repeat		
	Yellow/Brighness	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue/Brighness	Prime Video RANDOM	Blue / Prime Video / Random		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		