Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	S	OPT-TOOLS SETUP	Setup / OPT /
0	0	HDMI - SAT 0	0
	Source	RDS AV INPUT	AV / Input / RDS
DVD MENU MENU	Menu/Menu	HOME MENU	Menu / Home
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TV/FAV RADIO	Tv/Fav/Radio	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Rechange	
BACK EXIT	Exit/Back	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	PR+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	PR-	CH PAGE −	CH- / Page-
	[++]	LIST SMART	Smart / List
	→I [/] I ←	MEDIA DISPLAY	Display / Media
	[i +]	ANGLE INFO	Info / Angle
TEXT	Text	GOTO TEXT	Text / Goto
	I I >/ [▼]	SHIFT + TUNE+	Shift + >> /
	Play/ O) I / I I	SLOW	Play / Slow
	<</ [≡o]	TUNE-	<< / Tune-

Original		Rechange		Original	Rechange
SUBTITLE	>>/ Subtitle	TUNE+	>> / Tune+		
	Open/close/[≡?]	SURROUND	Eject / Surround		
	Stop/[≡+]	HOLD	Stop / Hold		
	I<<</[≡↕]	PRESET-	I<< / Preset-		
	>>I/[≡x]/[O]	PRESET+	>>I / Preset+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
DVD MENU MENU	_Menu/DVD	HOME MENU	Menu / Home
BACK EXIT	_ Exit/Back	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	_ Up		Up
	Left		Left
OK	OK	OK	OK

Original		Rechange	
	Right		Right
	Down		Down
	Vol -	VOL	Vol -
	Vol +	VOL	Vol +
	▮▮/▮▮▶ / [▼]	STEP-FREEZE	Pause / Step / Freeze
	▶ / I/II	SHIFT + SLOW	Shift + Play /
	▶ / I/II	SLOW	Play / Slow
	◀◀ / [≡]	TUNE-	<< / Tune-
	◀◀ / [≡]	SHIFT + TUNE-	Shift + << /
SUBTITLE	▶▶ / Subtitle	SHIFT + TUNE+	Shift + >> /
SUBTITLE	▶▶ / Subtitle	TUNE+	>> / Tune+
	▲	SURROUND	Eject / Surround
	■ / [≡]	HOLD	Stop / Hold
	▮◀◀ / [≡]	PRESET-	I<< / Preset-
	▮◀◀ / [≡]	SHIFT + PRESET-	Shift + I<< / Preset-
	▶▶▮ / [≡][≡X]	SHIFT + PRESET+	Shift + >>I / Preset+
	▶▶▮ / [≡][≡X]	PRESET+	>>I / Preset+

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	– 7	AUX - HDD 7	7
8	– 8	USB 8	8
9	– 9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	Source	RDS AV INPUT	AV / Input / RDS
	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL –	Vol -
	Vol +	VOL +	Vol +
	P-	CH PAGE –	CH- / Page-

Original		Rechange	
	▮▮/ ▮▮▶ / [▼]	STEP - FREEZE	Pause / Step / Freeze
	▶ / I/II	SHIFT + SLOW	Shift + Play /
	▶ / I/II	SLOW	Play / Slow
	◀◀ / [≡]	TUNE-	<< / Tune-
	◀◀ / [≡]	SHIFT + TUNE-	Shift + << /
SUBTITLE	▶▶ / Subtitle	SHIFT + TUNE+	Shift + >> /
SUBTITLE	▶▶ / Subtitle	TUNE+	>> / Tune+
	▲	SURROUND	Eject / Surround
	■ / [≡]	HOLD	Stop / Hold
	▮◀◀ / [≡]	SHIFT + PRESET-	Shift + I<< / Preset-
	▮◀◀ / [≡]	PRESET-	I<< / Preset-
	▶▶▮ / [ ][≡]	SHIFT + PRESET+	Shift + >>I / Preset+
	▶▶▮ / [ ][≡]	PRESET+	>>I / Preset+