Original	Rechange	Original	Rechange
Power	Power	Vol +	Vol +
Mute	Mute / Dimmer	Network	Smart / List
Play/Pause	Play / Slow	CH+	CH+ / Page+
I <</ Tune-	<< / Tune-	Vol -	Vol -
>>I / Tune+	>> / Tune+	Media Player	Display / Media
I <</ Tune-	I << / Preset-	CH-	CH- / Page-
>>I / Tune+	>>I / Preset+	Tv Audio	1
Sleep	Sleep / Timer	DVD	2
Setup	Setup / OPT /	CD	3
Option	Menu / Home	Blu-Ray	4
Up	Up	M-XPort	5
Info	Info / Angle	Tuner	6
Left	Left	AUX 1	7
Enter	OK	iPod/USB	8
Right	Right	Internet Radio	9
Down	Down	AUX 2	Guide / EPG / -/--
Back	Back / Return	CBL/SAT	0

Original	Rechange	Original	Rechange
Game	PC FAV MARKER Fav / Marker / PC		
Red/ Movie	NETFLIX SEARCH Red / Netflix / Search		
Green/ Music	APP REPEAT Green / APP / Repeat		
Yellow/ Pure	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue/ Game	Prime Video RANDOM Blue / Prime Video / Random		
Favorite Station 1	SHIFT + TV 1 Shift + 1		
Favorite Station 2	SHIFT + DVD 2 Shift + 2		
Favorite Station 3	SHIFT + CD - STB 3 Shift + 3		

Original	Rechange	Original	Rechange
Power	Power	Vol -	Vol -
Mute	Mute / Dimmer	Media Player	Display / Media
Play/Pause	Play / Slow	CH+	CH+ / Page-
I<</Tune-	<< / Tune-	Tv Audio	1
>>I / Tune+	>> / Tune+	DVD	2
I<</Tune-	I<< / Preset-	CD	3
>>I / Tune+	>>I / Preset+	Blu-Ray	4
Sleep	Sleep / Timer	M-XPort	5
Up	Up	Tuner	6
Left	Left	AUX 1	7
Enter	OK	iPod/USB	8
Right	Right	Internet Radio	9
Down	Down	AUX 2	Guide / EPG / -/--
Back	Back / Return	CBL/SAT	0
Vol +	Vol +	Game	Fav / Marker / PC
Network	Smart / List	Favorite Station 1	Shift + 1
CH+	CH+ / Page+	Favorite Station 2	Shift + 2

Original	Rechange	Original	Rechange
Favorite Station 3	SHIFT + CD-STB 3 Shift + 3		