Mandis shop

Iomega SCREENPLAY TV LINK DX

Original		Rechange	
	Power		Power
	Back	RETURN BACK	Back / Return
	☼	OPT-TOOLS SETUP	Setup / OPT /
	Home	HOME MENU	Menu / Home
	Browser	TOP MENU D.MENU	D. Menu / Top
	Up		Up
	Play/Pause	SLOW	Play / Slow
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Open/Close	SURROUND	Eject / Surround
	Search	NETFLIX SEARCH	Red / Netflix / Search
	Left		Left
Enter	OK	OK	OK
	Right		Right
	Stop	HOLD	Stop / Hold
	Vol -	VOL	Vol -
	Vol +	VOL	Vol +

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Down		Down
	Info	ANGLE INFO	Info / Angle
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
Fn	FN	GOTO TEXT	Text / Goto
Caps Lock	Caps Lock	RDS AV INPUT	AV / Input / RDS
Alt	Movie	EQ SUBTITLE	Subtitle / EQ
Space	Photo	FORMAT PICTURE	Picture / Format
Symbol	Music	TITLE SOUND	Sound / Title
Shift	Shift	Prime Video RANDOM	Blue / Prime Video / Random

https://al-rendecontrol.fr/iomega/1558420-telecommande-remplacement-pour-iomega-screenplay-tv-link-dx-screenplay-tv-link-dx.htm