Mandis shop

# Inno Hit RC1240-2440

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| M | M | TOP MENU MENU | Menu |
| | -- | -/-- GUIDE | Guide |
| | Up | | Up |
| OK | OK | OK | Ok |
| | Down | | Down |
| | Right | | Right |

| Original | | Rechange | |
|---|---|---|---|
| | Left | | Left |
| + P | P+ | + CH | Ch + |
| – | P- | CH – | Ch - |
| + V | Vol+ | + VOL | Vol + |
| – | Vol- | VOL – | Vol - |
| SOUND | Red | A | Red |
| SOUND | Sound | SOUND DUAL | Dual |
| PICTURE | Green | B | Green |
| PICTURE | Picture | PICTURE FORMAT | Format |
| FEATURE | Yellow | C | Yellow |
| FEATURE | Feature | APP MEDIA | Media |
| INSTALL | Blue | D | Blue |
| INSTALL | Install | HOME SMART | Smart |
| AV | AV | TIMER AV | AV |
| TV | TV | SEARCH TV/R | TV/R |
| TXT | TXT | REPEAT TEXT | Text |
| | Mute | MUTE | Mute |

https://all-remote-controls.nl/fr/Inno-Hit/1055734-27513-telecommande-de-remplacement-pour-Inno-Hit-RC1240-2440.html