Original		Rechange	
TV ⏻	Power	⏻	Power
1	Input 1	SHIFT + 1	Shift + 1
2	Input 2	SHIFT + 2	Shift + 2
3	Input 3	SHIFT + 3	Shift + 3
4	Input 4	SHIFT + 4	Shift + 4
5	Input 5	SHIFT + 5	Shift + 5
PC	PC	HOME SMART	Smart
HMG	HMG	APP MEDIA	Media
[i+]	[i+]/Timer/Info	DISPLAY INFO	Info
[▬]	[▬]	ECO 3D	3D
[↔]	[↔]	PICTURE FORMAT	Format
[←]	[←]	FAV PRE-CH	Pre Ch
HDMI CTRL	CTRL HDMI	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Original		Rechange	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
EPG	EPG/DVD Top Menu/Guide	GUIDE	Guide
TV/DTV/SAT	TV/DTV/SAT	SEARCH TV/R	TV/R
P+	P+	+ CH	Ch +
P-	P-	CH −	Ch -
Vol+	Vol+	+ VOL	Vol +
Vol-	Vol-	VOL −	Vol -
ENTER	Enter	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left

Original		Rechange	
EXIT	Exit	CLEAR EXIT	Exit
TOOLS	Tools	SETTINGS OPT	Options
HOME MENU	Home	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
	Mute	MUTE	Mute
CH RETURN	CH Return	E-MANUAL D.MENU	D. Menu
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Rec	REC MODE	Rec
	Pause	II	Pause
	Stop	■	Stop
	Play	PLAY MODE ▶	Play
	I<<	K<	I<<
	[...]	AD SUBT	Subt
	>>I	>>I	>>I

Original		Rechange	
	[≡?]	ZOOM ⏏	Eject
	<<	<<	<<
	>>	>>	>>
	[≡i]	DISC NAV LIST	List
	[≡]	REPEAT TEXT	Text
	[▬]DVD/[+]	SHIFT + SETTINGS OPT	Shift + Options
	[<>]/HDD	SHIFT + PICTURE FORMAT	Shift + Format
I-II	I-II	SOUND DUAL	Dual

Original		Rechange	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
EPG	EPG/DVD Top Menu/Guide	GUIDE	Guide
HOME MENU	Menu/Home	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
ENTER	Enter	OK	Ok
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Pause		Pause
	Stop		Stop
	Play	PLAY MODE	Play
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Vol+ Tv	VOL +	Vol +
	Vol- Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Rechange	
TV	Power		Power
[i+]	[i+]/Timer/Info	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
EPG	EPG/DVD Top Menu/Guide	GUIDE	Guide
P+	P+	CH +	Ch +
P-	P-	CH −	Ch -
EXIT	X/Exit	CLEAR EXIT	Exit
HOME MENU	Menu/Home	TOP MENU MENU	Menu

Original		Rechange	
RETURN	Return	RETURN BACK	Back
ENTER	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+ Tv	+ VOL	Vol +
	Vol- Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P+		Ch +
	P-		Ch -
	Rec		Rec
	Pause		Pause
	Stop		Stop
	Play		Play

Original		Rechange	
	I<<		I<<
	>>I		>>I
	Vol+ Tv		Vol +
	Vol- Tv		Vol -
	Mute Tv		Mute