Mandis shop

Philips CRP63201

Original	Rechange	Original	Rechange
Power	Power	Vol +	Vol +
Audio Source	Red	Vol -	Vol -
Play	Play	Treble	Ch +
Pause	Pause	Bass	Ch -
Radio	TV/R	Up	Up
USB	Yellow	Down	Down
MP3 Link	Blue	Right / >>	Right
Disc	Smart	Left / <<	Left
Audio	Dual	OK	Ok
Options	Options	1	1
Menu/ Back	Menu	2	2
[i] / Info	Info	3	3
Stop	Stop	4	4
Mute	Mute	5	5
>I	>>I	6	6
I <	I <<	7	7
Surround	Format	8	8

Original		Rechange	
9	9	9	9
0	0	0	0
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO SYNC	Audio Sync	APP MEDIA	Media
REPEAT PROGRAM	Repeat / Program	PROG SLEEP	Sleep
ZOOM	Zoom	ZOOM ⏏	Eject
REPEAT A-B	A-B/ Repeat	REPEAT TEXT	Text
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
▲	Up Radio	SHIFT + ▲	Shift + Up
▼	Down Radio	SHIFT + ▼	Shift + Down
▶ ▶▶	Right / >> Radio	SHIFT + ▶	Shift + Right
◀◀ ◀	Left / << Radio	SHIFT + ◀	Shift + Left
OK	OK Radio	SHIFT + OK	Shift + Ok
▶I	>I Radio	>>	>>
I◀	I < Radio	<<	<<
1	1 Radio	SHIFT + 1	Shift + 1
2	2 Radio	SHIFT + 2	Shift + 2

Original		Rechange	
3	3 Radio	SHIFT + 3	Shift + 3
4	4 Radio	SHIFT + 4	Shift + 4
5	5 Radio	SHIFT + 5	Shift + 5
6	6 Radio	SHIFT + 6	Shift + 6
7	7 Radio	SHIFT + 7	Shift + 7
8	8 Radio	SHIFT + 8	Shift + 8
9	9 Radio	SHIFT + 9	Shift + 9
0	0 Radio	SHIFT + 0	Shift + 0