| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Power | Power | Right | Right |
| [X] | Exit / Cancel / Clear | Vol + | Vol + |
| [♦] | Zoom / Size | Down | Down |
| [+] | Stop / Hold | P+ | CH+ / Page+ |
| [?]/[:≡] | Play / Slow | Vol - | Vol - |
| I.S. | Smart / List | Mute | Mute / Dimmer |
| [i+] | Info / Angle | P- | CH- / Page- |
| Sleep | Sleep / Timer | Red | Red / Netflix / Search |
| [<>] | Setup / OPT / | Green | Green / APP / Repeat |
| Smart ♪ | Sound / Title | Yellow | Yellow / YouTube / Repeat |
| Radio | TV/Radio / | Blue | Blue / Prime Video / Random |
| Smart [ ] | Picture / Format | 1 | 1 |
| Menu | Menu / Home | 2 | 2 |
| Up | Up | 3 | 3 |
| [≡] | Text / Goto | 4 | 4 |
| OK | OK | 5 | 5 |
| Left | Left | 6 | 6 |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| | Sour ce | RDS AV INPUT | AV / I nput / RDS | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| I-II | I - I I | LANG I/II AUDIO | Audi o / Lang I / I I | | |

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | Prog | PROGRAM TV/ RADIO | TV/ Radio / |
| | >> | TUNE+ | >> / Tune+ |
| MENU | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| OK | OK | OK | OK |
| | Left | | Left |
| | Right | | Right |
| | Down | | Down |
| | P+ | CH PAGE + | CH+ / Page+ |
| | P- | CH PAGE − | CH- / Page- |
| | Rec | REC MODE | Rec / Rec Mode |
| | << | TUNE- | << / Tune- |
| | Stop | HOLD | Stop / Hold |
| | Play | SLOW | Play / Slow |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |

| Original | | Rechange | |
|---|---|---|---|
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| | Source | RDS AV INPUT | AV / Input / RDS |
| 0 | 0 | HDMI - SAT 0 | 0 |