Original	Rechange	Original	Rechange
Power	Power	3	3
Red/ Sound↑	Red / Netflix / Search	4	4
Red/ Sound↑	Sound / Title	5	5
Green/ Picture/ ↓	Green / APP / Repeat	6	6
Green/ Picture/ ↓	Picture / Format	7	7
Yellow/ Feature	Yellow / YouTube / Repeat	8	8
Blue/ Install	Blue / Prime Video / Random	9	9
[≡]	Text / Goto	P<P	Display / Media
[≡0]	Play / Slow	0	0
[≡+]	Stop / Hold	-/--	Shift + Guide / EPG / -/--
[≡x] / [· ·]	Pause / Step / Freeze	Vol -	Vol -
[/ ≡] / [*]	Rec / Rec Mode	Vol +	Vol +
[+] ([≡♦] / Wide	Zoom / Size	Mute	Mute / Dimmer
[≡?] / PC	Fav / Marker / PC	P-	CH- / Page-
[≡i] / Guide	Guide / EPG / -/--	P+	CH+ / Page+
1	1	[i] / Info	Info / Angle
2	2	TV/ DTV	TV/ Radio / Program

Original		Rechange		Original	Rechange
	AV		AV / Input / RDS		
	I-II		Audio / Lang I/II		
	PP		Back / Return		
	Up		Up		
	Left		Left		
	OK/Select		OK		
	Right		Right		
	M		Menu / Home		
	Down		Down		