Original		Rechange	
AMP POWER	Power AMP		Power
POWER	Power CD	SHIFT +	Shift + Power
1 ./	1 CD	1	1
2 ABC	2 CD	2	2
3 DEF	3 CD	3	3
4 GHI	4 CD	4	4
5 JKL	5 CD	5	5
6 MNO	6 CD	6	6
7 PQRS	7 CD	7	7
8 TUV	8 CD	8	8
9 WXYZ	9 CD	9	9
0	0 CD	0	0
+10	+10 CD	-/-- GUIDE	Guide
CLEAR	Clear CD	FAV PRE-CH	Pre Ch
SOURCE	Source CD	TIMER AV	AV
MENU	Menu CD	TOP MENU MENU	Menu
MODE	Mode CD	SOUND DUAL	Dual

Original		Rechange	
INFO	Info CD	DISPLAY INFO	Info
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
PRESET	Preset + CD	CH +	Ch +
PRESET	Preset - CD	CH -	Ch -
ENTER	Enter CD	OK	Ok
	Up CD		Up
	Down CD		Down
	Right CD		Right
	Left CD		Left
PURE DIRECT	Pure Direct CD	SETTINGS OPT	Options
	Play/Pause CD	PLAY MODE	Play
	Stop CD		Stop
	<< CD		<<
	>> CD		>>
	I<< CD		I<<

Original		Rechange	
>>I CD		>>I	
Repeat CD	REPEAT	TEXT	Text
Program CD	PROGRAM	PROG SLEEP	Sleep
Random CD	RANDOM	AD SUBT	Subt
Dimmer CD	DIMMER	PICTURE FORMAT	Format
CD AMP	CD	SEARCH TV/R	TV/R
Recorder AMP	RECORDER	A	Red
Network AMP	NETWORK	CLEAR EXIT	Exit
Phono	PHONO	HOME SMART	Smart
Tuner	TUNER	RETURN BACK	Back
Internet Radio Preset 1	1	DISC NAV LIST	List
Internet Radio Preset 2	2	E-MANUAL D.MENU	D. Menu
Internet Radio Preset 3	3	ECO 3D	3D
Power NET	POWER	APP MEDIA	Media
Enter NET	ENTER	SHIFT + OK	Shift + Ok
Up NET		SHIFT +	Shift + Up
Down NET		SHIFT +	Shift + Down

Original		Rechange	
Right NET		SHIFT +	Shift + Right
Left NET		SHIFT +	Shift + Left
Pure Direct NET	PURE DIRECT	SHIFT + SETTINGS OPT	Shift + Options
1 NET	1 ./	SHIFT + 1	Shift + 1
2 NET	2 ABC	SHIFT + 2	Shift + 2
3 NET	3 DEF	SHIFT + 3	Shift + 3
4 NET	4 GHI	SHIFT + 4	Shift + 4
5 NET	5 JKL	SHIFT + 5	Shift + 5
6 NET	6 MNO	SHIFT + 6	Shift + 6
7 NET	7 PQRS	SHIFT + 7	Shift + 7
8 NET	8 TUV	SHIFT + 8	Shift + 8
9 NET	9 WXYZ	SHIFT + 9	Shift + 9
+10 NET	+10	SHIFT + -/-- GUIDE	Shift + Guide
0 NET	0 ␣.	SHIFT + 0	Shift + 0
Clear NET	CLEAR	SHIFT + FAV PRE-CH	Shift + Pre Ch
Mode NET	MODE	SHIFT + SOUND DUAL	Shift + Dual
<< NET		SHIFT +	Shift + <<

Original	Rechange	Original	Rechange
>> NET	Shift + >>		
Info NET	Shift + Info		
I<< NET	Shift + I<<		
>>I NET	Shift + >>I		
Stop NET	Shift + Stop		
Play/Pause NET	Shift + Play		
Preset + NET	Shift + Ch +		
Preset - NET	Shift + Ch -		
Menu NET	Shift + Menu		
Source NET	Shift + AV		
AUX	Shift + TV/R		
Dimmer NET	Shift + Format		
Random NET	Shift + Subt		
Program NET	Shift + Sleep		
Repeat NET	Shift + Text		