Original		Rechange	
	Power		Power
	Mute	MUTE	Mute
FUNCTION	Function	TOP MENU MENU	Menu
SOUND	Sound	SOUND DUAL	Dual
EQ	EQ	AD SUBT	Subt
DVD	DVD	APP MEDIA	Media
TIMER ON/OFF 1	1/Timer On/Off	1	1
TIMER/CLOCK 2	2/Timer/Clock	2	2
SLEEP 3	3/Sleep	3	3
DISC MENU 4	4/Disc Menu	4	4
TITLE MENU 5	5/Title Menu	5	5
6	6	6	6
7	7	7	7
SYNC 8	8/SYNC	8	8
9	9	9	9
0	0	0	0
VOL +	Vol +	+ VOL	Vol +

Original		Rechange	
VOL −	Vol -	VOL −	Vol -
RDS PTY	I<<<RDS PTY		I<<
	>>I		>>I
	<<		<<
RDS DISPLAY	>>/RDS Display		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
REPEAT	Repeat	REPEAT TEXT	Text
HOME	Home	HOME SMART	Smart
USB REC	USB Rec	REC MODE	Rec
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
TUNING	Up/Tuning Up		Up
	Down/Tuning		Down

Down

Original		Rechange	
# ▶	Right / #	▶	Right
◀ ♭	Left / b	◀	Left
⏎	Enter	OK	Ok
DISPLAY A	Red/ Display	A	Red
MO/ST B	GreenMo/ ST	B	Green
C	Yellow	C	Yellow
KEYCON D	Blue/ Keycon	D	Blue
CD REC SPEED	Speed/ CD Rec	ECO 3D	3D
MY KARAOKE	My Karaoke	SEARCH TV/R	TV/ R
MIC VOL +	Mic Vol +	+ CH	Ch +
MIC −	Mic Vol -	CH −	Ch -

Original	Rechange