Mandis shop

RM-SEP40

Original	Rechange	Original	Rechange
Power	Power	Stop	Stop
Volume +	Vol +	Tuner DSPL	Info
Volume -	Vol -	I <</ <<	<<
Music Menu	Menu	>>/ >>I	>>
Mega Bass	Media	Clock/Timer/Slee SET	Options
Tape	3	Timer On/Off	Exit
CD/Remain	1	Repeat	Text
Tuner/Band	2		
Preset +	Ch +		
Preset -	Ch -		
Tuning/Clock/Tin	Up		
Tuning/Clock/Tin	Down		
Tuner/Mem/Enter/	Ok		
Shuffle	3D		
RDS	Subt		
Play	Play		
Pause	Pause		

https://all-remote-controls.nl/fr/Sony/10509-8121-telecommande-de-replacement-pour-Sony-RM-SEP40.htm