Original	Rechange	Original	Rechange
Open/Close	Eject / Surround	Bass	Sound / Title
On/Standby	Power	Clear	Exit / Cancel / Clear
Play/Pause Bluetooth	Rec / Rec Mode	Vol -	Vol -
Play/Pause USB	Pause / Step / Freeze	Folder	Smart / List
Play/Pause CD	Play / Slow	Preset Up	>>I / Preset+
Pairing	9	Preset Up	Up
Stop	Stop / Hold	Play Mode	Menu / Home
Tuner	6	I <</ << Tuning	Left
Eco	D.Menu / Top	I <</ << Tuning	<< / Tune-
Display	Display / Media	Enter	OK
Input/Audio Line	AV / Input / RDS	Tuning >>/ >>I	Right
Sleep	Sleep / Timer	Tuning >>/ >>I	>> / Tune+
Dimmer	+ Shift + Mute / Dimmer	Memory	Setup / OPT /
Mute	Mute / Dimmer	Preset Down	I << / Preset-
Treble	Audio / Lang I/II	Preset Down	Down
X-Bass	Subtitle / EQ	Clock/Timer	+ Shift + Sleep / Timer
Vol +	Vol +	ASPM RDS	TV/Radio / Program

Original	Rechange	Original	Rechange
PTY RDS	Text / Goto		
DISP RDS	Info / Angle		