Mandis shop

Philips 996580009757

Original		Rechange	
	Power		Power
HDMI 1	HDMI 1	1	1
HDMI 2	HDMI 2	2	2
HDMI ARC	HDMI ARC	3	3
COAX	COAX	4	4
AUDIO IN	Audio In	5	5
OPTICAL	Optical	6	6
USB	USB	APP MEDIA	Media
	Bluetooth	OK	Ok
	Input	TIMER AV	AV
	I<		I<<
	Play / Pause	PLAY MODE	Play
	Play / Pause		Pause
	>I		>>I
BASS	Bass +		Up
BASS	Bass -		Down
	Vol +	VOL	Vol +

Original		Rechange	
	Vol -	VOL	Vol -
	Mute	MUTE	Mute
TREBLE	Treble +		Right
TREBLE	Treble -		Left
SMART	Smart	HOME SMART	Smart
MUSIC	Music	7	7
VOICE	Voice	8	8
MOVIE	Movie	9	9
HEIGHT	Height -	CH	Ch -
HEIGHT +	Height +	CH	Ch +
AUDIO SYNC	Audio Sync -	SHIFT +	Shift + Left
AUDIO SYNC +	Audio Sync +	SHIFT +	Shift + Right
NIGHT	Night	SETTINGS OPT	Options
AUTO VOL.	Auto Vol.	TOP MENU MENU	Menu
DIM	Dim	D	Blue
	Clock	SHIFT + TIMER AV	Shift + AV

https://al-remotes.fr/Philips/1384-978-telecommande-remplacement-pour-Philips-996580009757.html