Original		Rechange	
STANDBY	Standby		Power
INFO	Info	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
⏮	I<<	PRESET- ⏮	I<< / Preset-
▶	Play	SLOW ▶	Play / Slow
◀◀	<<	TUNE- ◀◀	<< / Tune-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
▶▶	>>	TUNE+ ▶▶	>> / Tune+
MENU	Menu	HOME MENU	Menu / Home
CH+ ▲	Up	▲	Up
CH+ ▲	CH+	+ CH PAGE	CH+ / Page+
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL- ◀	Vol -	VOL −	Vol -
VOL- ◀	Left	◀	Left
OK	OK	OK	OK

Original		Rechange	
VOL+ ▶	Right	▶	Right
VOL+ ▶	Vol +	+ VOL	Vol +
RECORD	Record	REC MODE	Rec / Rec Mode
CH- ▼	CH-	CH PAGE −	CH- / Page-
CH- ▼	Down	▼	Down
■	Stop	HOLD ■	Stop / Hold
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
BACK	Back	RETURN BACK	Back / Return
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Rechange		Original	Rechange
0	0	HDMI - SAT 0	0		
MEDIA	Media	MEDIA DISPLAY	Display / Media		
USB	USB	SHIFT + USB 8	Shift + 8		
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
TTX	TTX	GOTO TEXT	Text / Goto		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
RES	Res	LIST SMART	Smart / List		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original		Rechange	
STANDBY	Standby		Power
INFO	Info	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
⏮	I<<	PRESET- ⏮	I<< / Preset-
▶	Play	SLOW ▶	Play / Slow
◀◀	<<	TUNE- ◀◀	<< / Tune-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
▶▶	>>	TUNE+ ▶▶	>> / Tune+
MENU	Menu	HOME MENU	Menu / Home
CH+ ▲	Up / CH+	+ CH PAGE	CH+ / Page+
CH+ ▲	Up / CH+	▲	Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL- ◀	Left / Vol-	VOL −	Vol-
VOL- ◀	Left / Vol-	◀	Left
OK	OK	OK	OK

Original		Rechange	
VOL+ ▶	Right / Vol+	+ VOL	Vol+
VOL+ ▶	Right / Vol+	▶	Right
RECORD	Record	REC MODE	Rec / Rec Mode
CH- ▼	Down / CH-	▼	Down
CH- ▼	Down / CH-	CH PAGE −	CH- / Page-
■	Stop	HOLD ■	Stop / Hold
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
BACK	Back	RETURN BACK	Back / Return
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Rechange		Original	Rechange
0	0	0	0		
MEDIA	Media	MEDIA DISPLAY	Display / Media		
USB	USB	SHIFT + USB 8	Shift + 8		
TV/RADIO	TV / Radio	PROGRAM TV/RADIO	TV/Radio /		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
TTX	TTX	GOTO TEXT	Text / Goto		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
FAV	Fav	PC FAV MARKER	Fav / Marker / PC		
RES	Res.	LIST SMART	Smart / List		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		