Original		Rechange	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
VOL+	Vol +	+ VOL	Vol +
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
NICAM	Nicam	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange	
CH+	CH +	+ CH PAGE	CH+ / Page+
VOL-	Vol -	VOL −	Vol -
INPUT	Input	RDS AV INPUT	AV / Input / RDS
CH-	CH -	CH PAGE −	CH- / Page-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PMODE	PMode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
FAV-	FAV -	SHIFT +	Shift + Down

Original	Rechange
FAV +	SHIFT + Up (Shift + Up)
EPG	GUIDE EPG (Guide / EPG / -/--)
Text	GOTO TEXT (Text / Goto)
Hold	SHIFT + HOLD (Shift + Stop /)
Lang	SHIFT + LANG I/II AUDIO (Shift + Audio / Lang I/II)
Subtitle	EQ SUBTITLE (Subtitle / EQ)
Index / <<	TUNE- (<< / Tune-)
Index / <<	ANGLE INFO (Info / Angle)
Size / >>	TUNE+ (>> / Tune+)
Size / >>	SIZE ZOOM (Zoom / Size)
Reveal / I <<	PRESET- (I << / Preset-)
Subpage / >>I	PRESET+ (>>I / Preset+)
Subpage / >>I	SURROUND (Eject / Surround)
Rec	REC MODE (Rec / Rec Mode)
Play / Pause	SLOW (Play / Slow)
Play / Pause	STEP-FREEZE (Pause / Step / Freeze)
Stop	HOLD (Stop / Hold)

Original	Rechange
Media	SHIFT + MEDIA DISPLAY (Shift + Display / Media)
Red / TV/Radio	PROGRAM TV/RADIO (TV/Radio /)
Red / TV/Radio	NETFLIX SEARCH (Red / Netflix / Search)
Green	APP REPEAT (Green / APP / Repeat)
Yellow	YouTube REPEAT A-B (Yellow / YouTube / Repeat)
Blue	Prime Video RANDOM (Blue / Prime Video / Random)