Original		Rechange	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1 V1	V1	TV 1	1
2 V2	V2	VIDEO 4	4
3 V3	V3	AUX - HDD 7	7
5 MULTI CH	Multi CH	USB 8	8
6 DVD	DVD	DVD 2	2
7 TAPE	Tape	TAPE 5	5
8 TUNER	Tuner	TUNER 6	6
9 CD	CD	CD - STB 3	3
0 DIMMER	Tuner / Dimmer	HDMI - SAT 0	0
0 DIMMER	Tuner / Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CH DISC +	CH/Disc+	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
CH DISC –	CH/Disc-	CH PAGE –	CH- / Page-
VOL	Vol -	VOL –	Vol -

Original		Rechange	
GUIDE TOP MENU SP A/B	SP A/B	TITLE SOUND	Sound / Title
	Up		Up
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange	Original	Rechange
SURROUND Surround	SURROUND Eject / Surround		
SURROUND Surround	APP REPEAT Green / APP / Repeat		
<	YouTube REPEAT A-B Yellow / YouTube / Repeat		
>	Prime Video RANDOM Blue / Prime Video / Random		
AUDIO TEST TONE Test Tone	GOTO TEXT Text / Goto		
SUBTITLE CH SEL CH Sel	LIST SMART Smart / List		
RANDOM LEVEL- Level -	SHIFT + CH PAGE - Shift + CH- /		
REPEAT LEVEL+ Level +	SHIFT + CH PAGE + Shift + CH+ /		
DISPLAY Display	MEDIA DISPLAY Display / Media		
HDD L NIGHT L. Night / HDD	TOP MENU D.MENU D. Menu / Top		
DVD CINE FLTR Cine FLTR/ DVD	HOME MENU Menu / Home		

Original		Rechange	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD - STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX - HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10 10	+10	GUIDE EPG	Guide / EPG / -/--
0 DIMMER 11	0	HDMI - SAT 0	0
CLR SLEEP 12	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH DISC +	CH/Disc+	CH + PAGE	CH+ / Page+
CH DISC −	CH/Disc-	CH PAGE −	CH- / Page-
GUIDE TOP MENU SP A/B	Top Menu	TOP MENU D.MENU	D. Menu / Top Menu

Original		Rechange	
	Up		Up
PREVIOUS MENU MUTING	Muting/Previous Menu	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Muting/Previous Menu	DIMMER MUTE	Mute / Dimmer
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
AUDIO TEST TONE	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange		Original	Rechange
SUBTITLE CH SEL	Subtitle	EQ SUBTITLE	Subtitle / EQ		
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random		
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		

Original		Rechange	
ON	On		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
0 DIMMER 11	0	HDMI-SAT 0	0
CH DISC +	CH/Disc+	CH PAGE +	CH+ / Page+
CH DISC −	CH/Disc-	CH PAGE −	CH- / Page-
GUIDE TOP MENU SP A/B	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
PREVIOUS MENU MUTING	Muting/Previous Menu	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Muting/Previous Menu	DIMMER MUTE	Mute / Dimmer

Original		Rechange	
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
ON	On CD	SHIFT +	Shift + Power
STANDBY	Standby CD	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
1 V1	1 CD	SHIFT + TV 1	Shift + 1
2 V2	2 CD	SHIFT + DVD 2	Shift + 2
3 V3	3 CD	SHIFT + CD-STB 3	Shift + 3
4	4 CD	SHIFT + VIDEO 4	Shift + 4
5 MULTI CH	5 CD	SHIFT + TAPE 5	Shift + 5

Original		Rechange	
6 DVD	6 CD	SHIFT + TUNER 6	Shift + 6
7 TAPE	7 CD	SHIFT + AUX - HDD 7	Shift + 7
8 TUNER	8 CD	SHIFT + USB 8	Shift + 8
9 CD	9 CD	SHIFT + BLUETOOTH 9	Shift + 9
+10 10	+10 CD	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0 11 DIMMER	0 CD	SHIFT + HDMI - SAT 0	Shift + 0
CLR 12 SLEEP	CLR CD	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
CH DISC +	CH/Disc + CD	SHIFT + CH PAGE +	Shift + CH+ /
CH DISC −	CH/Disc- CD	SHIFT + CH PAGE −	Shift + CH- /
II	Pause CD	SHIFT + STEP - FREEZE II	Shift + Pause / Step /
►	Play CD	SHIFT + SLOW ►	Shift + Play /
■	Stop CD	SHIFT + HOLD ■	Shift + Stop /
◄◄	<< CD	SHIFT + TUNE- ◄◄	Shift + << /
►►	>> CD	SHIFT + TUNE+ ►►	Shift + >> /
I◄◄	I << CD	SHIFT + PRESET- I◄◄	Shift + I << / Preset-
►►I	>>I CD	SHIFT + PRESET+ ►►I	Shift + >>I / Preset+
RANDOM LEVEL-	Random CD	SHIFT + Prime Video RANDOM	Shift + Blue / Prime Video / Random

Original		Rechange	
REPEAT LEVEL+	Repeat CD	SHIFT + APP REPEAT	Shift + Green / APP /
DISPLAY	Display CD	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Rechange	
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD - STB 3	3
4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX - HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
0 DIMMER	0	HDMI - SAT 0	0
CH DISC +	CH+	CH PAGE +	CH+ / Page+
CH DISC −	CH-	CH PAGE −	CH- / Page-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK

Original		Rechange	
	Right		Right
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+