Original		Rechange	
	Power		Power
	PREMIUM NET	HOME SMART	Smart
Menu	Guida	GUIDE	Guide
Guida	Menu	TOP MENU MENU	Menu
Info	Info	DISPLAY INFO	Info
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	P +	+ CH	Ch +
	P -	CH −	Ch -
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow

Original		Rechange	
	Blue	D	Blue
Back	Back	RETURN BACK	Back
STOP Exit	Exit / Stop	CLEAR EXIT	Exit
STOP Exit	Exit / Stop		Stop
REW	<< REW		<<
FWD	>> FWD		>>
PAUSE/PLAY	Pause / Play	PLAY MODE	Play
PAUSE/PLAY	Pause / Play		Pause
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Rechange		Original	Rechange
0	0	0	0		
Lista	Lista	DISC NAV LIST	List		
Opzioni	Opzioni	SETTINGS OPT	Options		
TEXT	Text	REPEAT TEXT	Text		
TV/RAD	TV / Rad	SEARCH TV/R	TV/R		
APP	APP	SHIFT + APP MEDIA	Shift + Media		
Source	Source	TIMER AV	AV		
PREV	I<< Prev	I<<	I<<		
REC	Rec	REC MODE	Rec		
FILE	File	APP MEDIA	Media		
NEXT	>>I Next	>>I	>>I		