Original		Rechange	
	Power CD		Power
CD	CD	C	Yellow
PLAY	Play	PLAY MODE	Play
AUX	AUX	A	Red
VCR	VCR	HOME SMART	Smart
TV	TV	APP MEDIA	Media
TUNER	Tuner	B	Green
TAPE	Tape	D	Blue
DISPLAY	Display	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
DBB	DBB	-/-- GUIDE	Guide
DSC	DSC	FAV PRE-CH	Pre Ch
SLEEP	Sleep	PROG SLEEP	Sleep
SHUFFLE	Shuffle	SETTINGS OPT	Options
VOLUME +	Volume+	+ VOL	Vol +
VOLUME –	Volume-	VOL –	Vol -
BRIGHTNESS	Brightness	AD SUBT	Subt

Original		Rechange	
STOP	Stop CD		Stop
NEXT	Next >I CD		>>I
PREV.	I< Prev. CD		I<<
PAUSE	Pause CD		Pause
	>> CD		>>
	<< CD		<<
TV VOL +	Tv Vol +		Right
TV VOL –	Tv Vol -		Left
	Power AUX	SHIFT +	Shift + Power
	Power TV	SEARCH TV/R	TV/R

Original	Rechange	Original	Rechange
VCR	VCR	HOME SMART	Smart		
TV	TV	APP MEDIA	Media		
AUX	AUX	A	Red		
TUNER	Tuner	B	Green		
CD	CD	C	Yellow		
TAPE	Tape	D	Blue		
	Power VCR		Power		
MUTE	Mute	MUTE	Mute		
VOLUME +	Volume +	+ VOL	Vol +		
VOLUME –	Volume -	VOL –	Vol -		
PLAY	Play VCR	PLAY MODE	Play		
STOP	Stop VCR		Stop		
PAUSE	Pause VCR		Pause		
PREV.	I< Prev. VCR		I<<		
NEXT	Next >I VCR		>>I		
	<< VCR		<<		
	>> VCR		>>		

Original		Rechange	
TUNER	Tuner	B	Green
CD	CD	C	Yellow
VCR	VCR	HOME SMART	Smart
TV	TV	APP MEDIA	Media
AUX	Aux	A	Red
TAPE	Tape	D	Blue
	Power Tuner		Power
VOLUME +	Volume +	+ VOL	Vol +
VOLUME –	Volume -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
NEXT	Next >I Tuner		>>I
PREV.	I< Prev. Tuner		I<<
	<< Tuner		<<
	>> Tuner		>>

Original	Rechange

Original		Rechange	
TAPE	Tape	D	Blue
	Power Tape		Power
CD	CD	C	Yellow
TUNER	Tuner	B	Green
AUX	AUX	A	Red
VCR	VCR	HOME SMART	Smart
TV	TV	APP MEDIA	Media
SIDE	Side Tape	SOUND DUAL	Dual
MUTE	Mute	MUTE	Mute
VOLUME +	Volume +	+ VOL	Vol +
VOLUME –	Volume -	VOL –	Vol -
PLAY	Play Tape	PLAY MODE	Play
STOP	Stop Tape		Stop
NEXT	Next >I Tape		>>I
	<< Tape		<<
PREV.	I< Prev. Tape		I<<
PAUSE	Pause Tape		Pause

Original		Rechange	
	>> Tape		>>