Mandis shop

Pioneer AXD 7187

Original	Rechange	Original	Rechange
Standby AMP	Power	Stop CD	Stop
Standby CD	1	Play CD	Play
Standby Tuner	2	Disc Select	Smart
Standby Tape	3	- Station Tune	Ch -
Tape Select	Media	Station + Tune	Ch +
< Tape Deck II	Shift + Left	CD	4
< Tape Deck I	Left	Tuner	5
Stop Tape Deck I	Shift + Ok	Phono	6
Stop Tape Deck I	Ok	Tape 1	7
> Tape Deck I	Right	Tape 2	8
> Tape Deck II	Shift + Right	Line	9
<< Tape Deck I	<<	Vol +	Vol +
<< Tape Deck	Shift + <<	Vol -	Vol -
>> Tape Deck	Shift + >>		
>> Tape Deck I	>>		
I << CD	I <<		
>>I CD	>>I		

https://all-remote-controls.nl/fr/Pioneer/10965-501-telecommande-replacement-pour-Pioneer-CU-A018-AXD7187.html