Original		Rechange	
ON/STANDBY	On/Standby		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + USB 8	Shift + 8
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV / CD	SHIFT + TV 1	Shift + 1
TV/CD	TV / CD	SHIFT + CD - STB 3	Shift + 3
PORT	PORT	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc/Album	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
ALBUM	CH/Disc/Album	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -

Original		Rechange	
	Up		Up
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Home/Audio	HOME MENU	Menu / Home
AUDIO HOME	Home/Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange		Original		Rechange	
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat	CLR SLEEP 12	CLR/Sleep/12	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
THX PLAY MODE	THX	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
--/--10 +10 D.TUN DIMMER	+10/--/---10/Dimer/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--				
--/--10 +10 D.TUN DIMMER	+10/--/---10/Dimer/D.Tun	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer				
11 0	0/11	HDMI - SAT 0	0				
12 CLR SLEEP	CLR/Sleep/12	PC FAV MARKER	Fav / Marker / PC				
12 CLR SLEEP	CLR/Sleep/12	TIMER SLEEP	Sleep / Timer				

Original		Rechange	
ON/STANDBY	Power		Power
BD/DVD	DVD/BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + USB 8	Shift + 8
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV / CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV / CD	SHIFT + TV 1	Shift + 1
PORT	PORT	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
MUTING	Muting Receiver	DIMMER MUTE	Mute / Dimmer
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL −	Vol -
GUIDE/TOP MENU SP LAYOUT	Top Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home

Original		Rechange	
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

Original	Rechange	Original	Rechange
THX PLAY MODE — Play Mode	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
1 — 1	TV 1 — 1		
2 — 2	DVD 2 — 2		
3 — 3	CD-STB 3 — 3		
4 — 4	VIDEO 4 — 4		
5 — 5	TAPE 5 — 5		
6 — 6	TUNER 6 — 6		
7 — 7	AUX-HDD 7 — 7		
8 — 8	USB 8 — 8		
9 — 9	BLUETOOTH 9 — 9		
+10 D.TUN DIMMER — +10/--/--10/D.Tu Dimmer	GUIDE EPG — Guide / EPG / -/--		
0 11 — 0/11	HDMI-SAT 0 — 0		
CLR SLEEP 12 — CLR/Sleep/12	PC FAV MARKER — Fav / Marker / PC		
CLR SLEEP 12 — CLR/Sleep/12	TIMER SLEEP — Sleep / Timer		
CLR SLEEP 12 — CLR/Sleep/12	CLEAR EXIT CANCEL — Exit / Cancel / Clear		

Original		Rechange	
ON/STANDBY	Power		Power
BD/DVD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + USB 8	Shift + 8
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV/CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV/CD	SHIFT + TV 1	Shift + 1
PORT	PORT	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
MUTING	Muting Receiver	DIMMER MUTE	Mute / Dimmer
CH DISC +	CH/Disc+	CH PAGE +	CH+ / Page+
VOL +	Vol + Receiver	VOL +	Vol +
ALBUM −	CH/Disc-	CH PAGE −	CH- / Page-
VOL −	Vol - Receiver	VOL −	Vol -
	Up		Up

Original		Rechange	
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

Original		Rechange		Original	Rechange
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
--/--- 10 +10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Dimmer	-/-- GUIDE EPG	Guide / EPG / - / - -		
11 0	0/ 11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
12 CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		

Original		Rechange	
ON/STANDBY	Power Receiver		Power
MUTING	Muting Receiver	DIMMER MUTE	Mute / Dimmer
CH DISC	CH	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
ALBUM	CH Disc/Album	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
	Up		Up
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO HOME	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Original		Rechange	
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie TV	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat
THX PLAY MODE	Stereo	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Rechange		Original	Rechange
+10/ - - / - - 10/ D. Tu Dimmer		Guide / EPG / -/ - -			
+10/ - - / - - 10/ D. Tu Dimmer		SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
0/ 11		0			
CLR/ Sleep/ 12		Fav / Marker / PC			
CLR/ Sleep/ 12		Exit / Cancel / Clear			
CLR/ Sleep/ 12		Sleep / Timer			