Original		Rechange	
	Power		Power
TV/AV	Tv/AV	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Back	RETURN BACK	Back / Return
V+	Vol +	+ VOL	Vol +
SCAN	Scan	LIST SMART	Smart / List
P+	P+	+ CH PAGE	CH+ / Page+

Original		Rechange	
V-	Vol -	VOL −	Vol -
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
P-	P-	CH PAGE −	CH- / Page-
	Up		Up
	Left		Left
OK SELECT	OK/Select	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Red / Picture	NETFLIX SEARCH	Red / Netflix / Search
	Red / Picture	FORMAT PICTURE	Picture / Format
	Green / Sound	APP REPEAT	Green / APP / Repeat
	Green / Sound	TITLE SOUND	Sound / Title
SLEEP	Yellow / Sleep	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SLEEP	Yellow / Sleep	TIMER SLEEP	Sleep / Timer
CALL	Blue / Call	Prime Video RANDOM	Blue / Prime Video / Random

Original		Rechange		Original	Rechange
TEXT	Text	GOTO TEXT	Text / Goto		
MIX	Mix	SHIFT + GOTO TEXT	Shift + Text /		
SIZE	Size	SHIFT + SIZE ZOOM	Shift + Zoom /		
INDEX	Index	REC MODE	Rec / Rec Mode		
HOLD	Hold	HOLD	Stop / Hold		
REVEAL	Reveal	SLOW	Play / Slow		
SUBPAGE	Subpage	EQ SUBTITLE	Subtitle / EQ		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
DVB MENU	DVB Menu	TOP MENU D.MENU	D. Menu / Top		
i	i	ANGLE INFO	Info / Angle		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
ESC	ESC	PC FAV MARKER	Fav / Marker / PC		
DVB	DVB	MEDIA DISPLAY	Display / Media		
FREEZE	Freeze	STEP-FREEZE	Pause / Step / Freeze		
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II		