Original		Rechange	
	Power		Power
SLEEP	Sl eep	PROG SLEEP	Sl eep
MUTE	Mut e	MUTE	Mut e
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+ ASPECT	10+ / Aspect	SHIFT +	GUIDE Shi f t + Gui de
SUBTITLE	Subt i t l e	AD SUBT	Subt
SOURCE	Sour ce	TIMER AV	AV
P.STD	- [/] - / P. ST	SHIFT +	PICTURE FORMAT Shi f t + For mat

Original		Rechange	
S.STD	- [♪] - / S. STD	SHIFT +	SOUND DUAL Shi f t + Dual
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Lef t		Lef t
OK	OK	OK	Ok
	Ri ght		Ri ght
	Down		Down
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Pr ogr am +	+ CH	Ch +
	Pr ogr am -	CH −	Ch -
EXIT	Exi t	CLEAR EXIT	Exi t
EXIT	Open / Cl ose	ZOOM	Ej ect
INFO	I nf o	DISPLAY INFO	I nf o
DVD/FAV	Set up / DVD / FA	SETTINGS OPT	Opt i ons
AUDIO	I / I I / Audi o	SOUND DUAL	Dual
TTX	[/ ≡] / Text	REPEAT TEXT	Text

Original		Rechange	
PLAY/TTX	Play	PLAY MODE ▶	Play
PLAY/TTX	Pause	❚❚	Pause
■/EPG	Stop	■	Stop
■/EPG	[≡x] / EPG	-/-- GUIDE	Guide
TITLE/ADD	[≡♦] / Title / A	SEARCH TV/R	TV/R
VENU/SUB.	Menu / SUB.	E-MANUAL D.MENU	D. Menu
GOTO	[≡+] / Goto	PICTURE FORMAT	Format
SLOW	[≡?] / Slow	HOME SMART	Smart
REPEAT	[≡o] / Repeat	ECO 3D	3D
A-B	[≡i] / A-B	APP MEDIA	Media
⏮	I<<	K<	I<<
⏮	Red	A	Red
⏭	>>I	>>	>>I
⏭	Green	B	Green
◀◀	<<	<<	<<
◀◀	Yellow	C	Yellow
▶▶	>>	>>	>>

Original		Rechange	
▶▶	Blue	D	Blue