Original		Rechange	
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
STANDBY/ON ⏻/I DVD	Standby DVD		Power
TV1 1	1	TV 1	1
TV2 2	2	DVD 2	2
TV3 3	3	CD - STB 3	3
TV4 4	4	VIDEO 4	4
TV5 5	5	TAPE 5	5
TV6 6	6	TUNER 6	6
TV7 7	7	AUX - HDD 7	7
TV8 8	8	USB 8	8
TV9 9	9	BLUETOOTH 9	9
TV-/-- 10	10	-/-- GUIDE EPG	Guide / EPG / -/--
TV0 0	0	HDMI - SAT 0	0
MUTING +10	+10	PC FAV MARKER	Fav / Marker / PC
RETURN	Return	RETURN BACK	Back / Return
TITLE/ GROUP	Title/Group	TITLE SOUND	Sound / Title
TV/VIDEO CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Rechange	
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
CH +	Up		Up
MENU	Menu	HOME MENU	Menu / Home
VOL –	Left		Left
ENTER	Enter	OK	OK
VOL +	Right		Right
CHOICE	Choice	LIST SMART	Smart / List
CH –	Down		Down
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media
PREVIOUS	I <<</ Previous	PRESET-	I << / Preset-
NEXT	>>I / Next	PRESET+	>>I / Preset+
CLEAR	Stop/Clear	HOLD	Stop / Hold
CLEAR	Stop/Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
SELECT	Play/Select	SLOW	Play / Slow
STROBE	Pause/Strobe	STEP - FREEZE	Pause / Step / Freeze
SLOW –	<<</ Slow-	TUNE-	<< / Tune-
SLOW +	>>/ Slow+	TUNE+	>> / Tune+

Original		Rechange		Original	Rechange
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat		
SUB TITLE	Sub Title	EQ / SUBTITLE	Subtitle / EQ		
AUDIO	Audio	LANG I/II / AUDIO	Audio / Lang I/II		
VFP	VFP	OPT-TOOLS / SETUP	Setup / OPT /		
DIGEST	Digest	GOTO / TEXT	Text / Goto		
ANGLE	Angle	ANGLE / INFO	Info / Angle		
− ZOOM	Zoom-	CH PAGE −	CH- / Page-		
ZOOM +	Zoom+	+ CH PAGE	CH+ / Page+		
3D PHONIC	3D Phonic	SHIFT + CD-STB 3	Shift + 3		
− AMP VOL	AMP Vol -	VOL −	Vol -		
AMP VOL +	AMP Vol +	+ VOL	Vol +		

Original	Rechange	Original	Rechange
Standby TV	Power	CH-	CH- / Page-
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
-/--	Guide / EPG / -/--		
0	0		
Muting	Mute / Dimmer		
Tv/Video	Smart / List		
CH+	CH+ / Page+		
Vol -	Vol -		
Vol +	Vol +		