Mandis shop

Sony RMT-CDS11IP

Original		Rechange	
OFF	Off		Power
MODE	Mode	PICTURE FORMAT	Format
RADIO BAND	Radio/Band	SEARCH TV/R	TV/R
AUDIO IN	Audio In	TIMER AV	AV
TUNE -	I<</Tune-		I<<
	Play	PLAY MODE	Play
	Pause		Pause
TUNE +	>>I/Tune+		>>I
PRESET +	Preset+	+ CH	Ch +
PRESET -	Preset-	CH -	Ch -
	Up		Up
	Down		Down
VOL +	Vol+	+ VOL	Vol +
VOL -	Vol-	VOL -	Vol -
MENU	Menu	TOP MENU MENU	Menu
ENTER	Enter	OK	Ok
MEGA BASS	Mega Bass	HOME SMART	Smart

Original		Rechange	
MEGA Xpand	Mega Xpand	APP MEDIA	Media
SNOOZE	Snooze	MUTE	Mute

https://all-remote-controls.nl/fr/Sony/1061121-90796-telecommande-de-remplacement-pour-Sony-RMT-CDS11IP-988514353.html