Mandis shop

ROTEL RR927- AMP2

Original	Rechange	Original	Rechange
Standby AMP	Power	Vol -	Vol -
Phono	1	On Screen	Options
Tuner	AV	CTR FCS	Guide
AUX1	2	< SRND Mode	Ch -
AUX 2	3	SRND Mode >	Ch +
Tape 1	4	BAL CHK	Dual
Tape 2	5	< Delay Time	Down
Video 1	6	Delay Time >	Up
Video 2	7	>> Tape	>>
Video 3	8	<< Tape	<<
Off	Exit	Play Tape	Play
Rec/Zone	List	Pause Tape	Pause
Band	0	Rec Tape	Rec
A Tun	Pre Ch	Stop Tape	Stop
< Tuning	Left		
Tuning >	Right		
Vol +	Vol +		

https://all-remote-controls.nl/fr/ROTEL/16184675-telecommande-replacement-pour-ROTEL-RR927-AMP2.htm