Mandis shop

RMT-CS200AD

Original	Rechange	Original	Rechange
Operate (AC Only)	Power		
Function	Menu		
Band	TV/R		
Play/Pause	Play		
Play	Yellow		
Pause	Pause		
>>I/Preset+	>>I		
>>/Tune+	>>		
I<</Preset-	I<<		
<</Tune-	<<		
Stop	Stop		
Vol+	Vol +		
Vol-	Vol -		

https://all-remote-controls.nl/fr/Sony/1062926-91480-telecommande-de-remplacement-pour-Sony-RMT-CS200AD.html