Original	Rechange	Original	Rechange
Power Receiver	Power	Up	Up
BD/DVD	Shift + 2	Left Playlist	Left
CBL/SAT	Shift + 0	Enter	OK
Game	Shift + 9	Right Playlis	Right
PC	Shift + Fav / Marker / PC	Q/Setup	Setup / OPT /
AUX	Shift + 7	Down	Down
TUNER	Shift + 6	Return	Back / Return
TV/CD	Shift + 3	Home/Audio	Audio / Lang I/II
Phono	Shift + 4	I <<	I << / Preset-
NET	Shift + Guide / EPG / -/--	<<	<< / Tune-
USB	Shift + 8	>>	>> / Tune+
Display	Display / Media	>>I	>>I / Preset+
Muting	Mute / Dimmer	Pause	Pause / Step / Freeze
CH/Disc/Album	CH+ / Page+	Play	Play / Slow
Vol +	Vol +	Stop	Stop / Hold
CH/Disc/Album	CH- / Page-	Movie/Tv/Search/	Red / Netflix / Search
Vol -	Vol -	Music/Repeat/B	Green / APP / Repeat

Original		Rechange		Original	Rechange
RANDOM GAME C	Game/ Random/	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
MODE STEREO D	Stereo/ Mode/ D	Prime Video RANDOM	Blue / Prime Video / Random		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10 D.TUN DIMMER	+10/ - -/ - - - 10/ Dimer/ D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--		
11 0	0/ 11	HDMI - SAT 0	0		
12 CLR SLEEP	CLR/ Sleep/ 12	PC FAV MARKER	Fav / Marker / PC		
12 CLR SLEEP	CLR/ Sleep/ 12	TIMER SLEEP	Sleep / Timer		
12 CLR SLEEP	CLR/ Sleep/ 12	CLEAR EXIT CANCEL	Exit / Cancel / Clear		

Original	Rechange	Original	Rechange
Power BD/DVD	Power	Down BD/DVD	Down
Play BD/DVD	Play / Slow	Return BD/DVD	Back / Return
Pause BD/DVD	Pause / Step / Freeze	Vol + Receiver	Vol +
Stop BD/DVD	Stop / Hold	BD/DVD	Smart / List
<< BD/DVD	<< / Tune-	Vol - Receiver	Vol -
>> BD/DVD	>> / Tune+	CBL/SAT	Display / Media
I<< BD/DVD	I<< / Preset-	1 BD/DVD	1
>>I BD/DVD	>>I / Preset+	2 BD/DVD	2
Audio BD/DVD	Audio / Lang I/II	3 BD/DVD	3
Top Menu	D.Menu / Top	4 BD/DVD	4
Setup BD/DVD	Setup / OPT /	5 BD/DVD	5
Menu BD/DVD	Menu / Home	6 BD/DVD	6
Up BD/DVD	Up	7 BD/DVD	7
Left BD/DVD	Left	8 BD/DVD	8
Enter BD/DVD	OK	9 BD/DVD	9
Right BD/DVD	Right	+10/--/--10	Guide / EPG / -/--
CLR/12 BD/DVD	Exit / Cancel / Clear	0/11 BD/DVD	0

Original	Rechange	Original	Rechange
CLR/12 BD/DVD	Fav / Marker / PC	Down CBL/SAT	Shift + Down
Search BD/DVD	Red / Netflix / Search	Return CBL/SAT	Shift + Back / Return
Repeat BD/DVD	Green / APP / Repeat	CH Disc/Album+ CBL/SAT	Shift + CH+ /
Stereo/Mode	Yellow / YouTube / Repeat	CH Disc/Album- CBL/SAT	Shift + CH- /
Random	Blue / Prime Video / Random	1 CBL/SAT	Shift + 1
Power CBL/SAT	Shift + Power	2 CBL/SAT	Shift + 2
Play CBL/SAT	Shift + Play /	3 CBL/SAT	Shift + 3
Pause CBL/SAT	Shift + Pause / Step /	4 CBL/SAT	Shift + 4
Stop CBL/SAT	Shift + Stop /	5 CBL/SAT	Shift + 5
<< CBL/SAT	Shift + << /	6 CBL/SAT	Shift + 6
>> CBL/SAT	Shift + >> /	7 CBL/SAT	Shift + 7
Setup CBL/SAT	Shift + Setup / OPT / Tools	8 CBL/SAT	Shift + 8
Menu/Prev CH CBL/SAT	Shift + Menu /	9 CBL/SAT	Shift + 9
Up CBL/SAT	Shift + Up	Guide CBL/SAT	Shift + Guide / EPG / -/--
Left CBL/SAT	Shift + Left	0/11 CBL/SAT	Shift + 0
Enter CBL/SAT	Shift + OK	Movie Tv/Search CBL/SAT	Shift + Red / Netflix /
Right CBL/SAT	Shift + Right	Music/Repeat CBL/SAT	Shift + Green / APP / Repeat

Original		Rechange		Original	Rechange
RANDOM GAME C	Game/ Random	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
MODE STEREO D	Stereo/ Mode	SHIFT + Prime Video RANDOM	Shift + Blue / Prime		

Original	Rechange	Original	Rechange
Power CD	Power	TV/CD	Smart / List
Play CD	Play / Slow	CH/Disc+ CD	CH+ / Page+
Pause CD	Pause / Step / Freeze	Vol - Receiver	Vol -
Stop CD	Stop / Hold	CH/Disc- CD	CH- / Page-
<< CD	<< / Tune-	1 CD	1
>> CD	>> / Tune+	2 CD	2
I << CD	I << / Preset-	3 CD	3
>>I CD	>>I / Preset+	4 CD	4
Audio CD	Audio / Lang I/II	5 CD	5
Setup CD	Setup / OPT /	6 CD	6
Up CD	Up	7 CD	7
Left CD	Left	8 CD	8
Enter CD	OK	9 CD	9
Right CD	Right	+10/--/--10/D.Tun Dimmer CD	Guide / EPG / -/--
Down CD	Down	0/11 CD	0
Return CD	Back / Return	CLR/Sleep/12	Fav / Marker / PC
Vol + Receiver	Vol +	Search CD	Red / Netflix / Search

Original	Rechange	Original	Rechange
REPEAT MUSIC B — Repeat CD	APP REPEAT — Green / APP / Repeat		
MODE STEREO D — Mode CD	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
RANDOM GAME C — Random CD	Prime Video RANDOM — Blue / Prime Video / Random		

Original	Rechange	Original	Rechange
Power Receiver Zone 2	Power	>> Zone 2	>> / Tune+
CH Disc/Album+ Zone 2	CH+ / Page+	Pause Zone 2	Pause / Step / Freeze
Vol + Zone 2	Vol +	Stop Zone 2	Stop / Hold
CH Disc/Album- Zone 2	CH- / Page-	Movie Tv Zone	Red / Netflix / Search
Vol - Zone 2	Vol -	Music Zone 2	Green / APP / Repeat
Up Zone 2	Up	Game Zone 2	Yellow / YouTube / Repeat
Left Zone 2	Left	Stereo Zone 2	Blue / Prime Video / Random
Enter Zone 2	OK	1 Zone 2	1
Right Zone 2	Right	2 Zone 2	2
Setup Zone 2	Setup / OPT /	3 Zone 2	3
Down Zone 2	Down	4 Zone 2	4
Return Zone 2	Back / Return	5 Zone 2	5
Audio Zone 2	Audio / Lang I/II	6 Zone 2	6
I << Zone 2	I << / Preset-	7 Zone 2	7
>>I Zone 2	>>I / Preset+	8 Zone 2	8
<< Zone 2	<< / Tune-	9 Zone 2	9
Play Zone 2	Play / Slow	+10/--/--10/D.Tun Dimmer Zone 2	Guide / EPG / -/--

Original	Rechange	Original	Rechange
0/11 Zone 2	0		
CLR/Sleep/12	Fav / Marker / PC		