Original		Rechange	
	On		Power
	Off	SHIFT +	Shift + Power
	Mute	DIMMER MUTE	Mute / Dimmer
AVR	AVR	LIST SMART	Smart / List
DVD	DVD	SHIFT + DVD 2	Shift + 2
CD	CD	SHIFT + CD - STB 3	Shift + 3
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
VCR VID1	VID1/VCR	SHIFT + VIDEO 4	Shift + 4
TV VID2	VID2/TV	SHIFT + TV 1	Shift + 1
CBL/SAT VID3	VID3/CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
AM/FM	AM/FM	SHIFT + TUNER 6	Shift + 6
6 CH.	6 CH	SHIFT + AUX - HDD 7	Shift + 7
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TEST	Test	GOTO TEXT	Text / Goto
	Input	RDS AV INPUT	AV / Input / RDS
VOL	Vol +	+ VOL	Vol +

Original		Rechange	
PR SURR	Surr.	SURROUND	Eject / Surround
NIGHT	Night	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
	[≡]	SHIFT + GOTO TEXT	Shift + Text /
VOL	Vol -	VOL −	Vol -
CH.	CH. / [≡?]	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
MENU SPKR	SPKR/Menu	HOME MENU	Menu / Home
	Left		Left
SET	Set	OK	OK
	Right		Right
DIGITAL	Digital / [≡X]	MEDIA DISPLAY	Display / Media
	Down		Down
DELAY NORMAL	Delay/Normal	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4

Original		Rechange	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
TUN-M	Tun- M/ [≡+]	+ CH PAGE	CH+ / Page+
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
MEM	Mem/ [≡♦]	CH PAGE –	CH- / Page-
▲	Tuning ▲ / Red	TUNE+ ▶▶	>> / Tune+
▲	Tuning ▲ / Red	NETFLIX SEARCH	Red / Netflix / Search
DIRECT	Direct/Green	APP REPEAT	Green / APP / Repeat
CLEAR	Clear/Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
CLEAR	Clear/Yellow	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Preset ▲ / Blue	PRESET+ ▶▶I	>>I / Preset+
▲	Preset ▲ / Blue	Prime Video RANDOM	Blue / Prime Video / Random
▼	Tuning▼	TUNE- ◀◀	<< / Tune-
RDS	RDS/ D. Skip	ANGLE INFO	Info / Angle

Original		Rechange	
▼	Preset ▼	PRESET- I◀◀	I<< / Preset-
	Dolby	TITLE SOUND	Sound / Title
	DTS Surr.	SHIFT + SURROUND ⏏	Shift + Eject / Surround
	DTS Neo 6	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
	Logic 7	EQ SUBTITLE	Subtitle / EQ
	Stereo	LANG I/II AUDIO	Audio / Lang I/II
DWN SKIP	Skip Dwn DVD	SHIFT + PRESET- I◀◀	Shift + I<< / Preset-
SKIP UP	Skip Up DVD	SHIFT + PRESET+ ▶▶I	Shift + >>I / Preset+
	<< DVD	SHIFT + TUNE- ◀◀	Shift + << /
	Play DVD	SHIFT + SLOW ▶	Shift + Play /
	>> DVD	SHIFT + TUNE+ ▶▶	Shift + >> /
	Stop DVD	SHIFT + HOLD ■	Shift + Stop /
	Pause DVD	SHIFT + STEP - FREEZE II	Shift + Pause / Step /

Original		Rechange	
	Power On		Power
	Power Off	SHIFT +	Shift + Power
VOL	Vol +	VOL +	Vol +
NIGHT	Night	TIMER SLEEP	Sleep / Timer
	[≡]	GOTO TEXT	Text / Goto
VOL	Vol -	VOL −	Vol -
CH.	CH. / [≡?]	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
MENU SPKR	SPKR/Menu	HOME MENU	Menu / Home
	Left		Left
SET	Set	OK	OK
	Right		Right
DIGITAL	Digital / [≡X]	TOP MENU D.MENU	D. Menu / Top
	Down		Down
DELAY NORMAL	Delay/Normal	RETURN BACK	Back / Return
1	1	TV 1	1
2	2	DVD 2	2

Original		Rechange	
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
TUN-M	Tun-M/[≡+]	LIST SMART	Smart / List
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEM	Mem/[≡♦]	MEDIA DISPLAY	Display / Media
DIRECT	Direct	TITLE SOUND	Sound / Title
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Preset ▲	CH PAGE +	CH+ / Page+
RDS	RDS/D.Skip	SURROUND	Eject / Surround
	Preset ▼	CH PAGE −	CH- / Page-
DWN SKIP	I<<	PRESET-	I<< / Preset-
SKIP UP	>>I	PRESET+	>>I / Preset+

Original	Rechange	Original	Rechange
<<	TUNE- << / Tune-		
Play	SLOW Play / Slow		
>>	TUNE+ >> / Tune+		
Stop	HOLD Stop / Hold		
Pause	STEP-FREEZE Pause / Step / Freeze		

Original	Rechange	Original	Rechange
Power On	Power	Preset ▲/ Blue	Blue / Prime Video / Random
Power Off	Shift + Power	RDS/ D. Skip	Eject / Surround
SPKR/ Menu	Menu / Home	I <<	I << / Preset-
Delay/ Normal	Back / Return	>>I	>>I / Preset+
1	1	<<	<< / Tune-
2	2	Play	Play / Slow
3	3	>>	>> / Tune+
4	4	Stop	Stop / Hold
5	5	Pause	Pause / Step / Freeze
6	6		
7	7		
8	8		
Tun- M/ [≡+]	Smart / List		
9	9		
0	0		
Mem/ [≡♦]	Display / Media		
Direct	Sound / Title		

Original		Rechange		Original	Rechange
	<<	TUNE-	<< / Tune-		
	<>	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		