Original	Rechange	Original	Rechange
Power	Power	i / OSD	Display / Media
1	1	Z/ Disc Menu	Menu / Home
2	2	Up	Up
3	3	P+	CH+ / Page+
PIP	Info / Angle	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
[<>]	Picture / Format	Vol +	Vol +
>I	>>I / Preset +	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	Down	Down
9	9	P-	CH- / Page-
?	Smart / List	TV- G	Guide / EPG / -/--
I <	I << / Preset -	>>	>> / Tune+
0	0	Red/ Image/ I >	Red / Netflix / Search
Mute	Mute / Dimmer	Green/ Timer	Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	Play / Slow		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original	Rechange	Original	Rechange
Power	Power	Disc Menu	D. Menu / Top
1	1	Disc Menu	Menu / Home
2	2	Up	Up
3	3	P+	CH+ / Page+
Audio	Audio / Lang I/II	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
[<>]	Zoom / Size	Vol +	Vol +
>I	>>I / Preset+	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	Down	Down
9	9	P-	CH- / Page-
?	Smart / List	TV-G	Guide / EPG / -/--
I <	I << / Preset-	>>	>> / Tune+
0	0	Red/Picture	Picture / Format
i / OSD	Display / Media	Red/Picture	Red / Netflix / Search

Original	Rechange	Original	Rechange
Green / Timer	TIMER SLEEP Sleep / Timer		
Play	SLOW Play / Slow		
Green / Timer	APP REPEAT Green / APP / Repeat		
Yellow/Pause	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Pause	STEP-FREEZE Pause / Step / Freeze		
Blue/Sound	TITLE SOUND Sound / Title		
Stop	HOLD Stop / Hold		
Blue/Sound	Prime Video RANDOM Blue / Prime Video / Random		

Original	Rechange	Original	Rechange
Power	Power	i / OSD	Display / Media
1	1	Z/ Disc Menu	Menu / Home
2	2	Up	Up
3	3	P+	CH+ / Page+
Audio	Audio / Lang I/II	Left	Left
4	4	Vol -	Vol -
5	5	OK	OK
6	6	Right	Right
[<>]	Zoom / Size	Vol +	Vol +
>I	>>I / Preset+	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	Down	Down
9	9	P-	CH- / Page-
?	Smart / List	TV-G	Guide / EPG / -/--
I <	I << / Preset-	>>	>> / Tune+
0	0	Red/ Image/ I >	Red / Netflix / Search
Mute	Mute / Dimmer	Red/ Image/ I >	Shift + Play / Slow

Original	Rechange	Original	Rechange
Green/Timer	Green / APP / Repeat		
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Pause	Pause / Step / Freeze		
Yellow/Pause	Yellow / YouTube / Repeat		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		

Original	Rechange	Original	Rechange
Power	Power	Z/ Disc Menu	Menu / Home
1	1	P+	CH+ / Page+
2	2	Up	Up
3	3	Left	Left
PIP/ Audio	Audio / Lang I/II	Vol -	Vol -
4	4	OK	OK
5	5	Right	Right
6	6	Vol +	Vol +
[<>]	Zoom / Size	TXT	Text / Goto
7	7	<<	<< / Tune-
8	8	P-	CH- / Page-
9	9	Down	Down
?	Smart / List	TV-G	Guide / EPG / -/--
I <	I << / Preset-	>>	>> / Tune+
>I	>>I / Preset+	Red/ Image/ I >	Picture / Format
0	0	Red/ Image/ I >	Red / Netflix / Search
i / OSD	Display / Media	Green/ Timer	Green / APP / Repeat

Original	Rechange	Original	Rechange
Play	Play / Slow		
Green/Timer	Sleep / Timer		
Yellow/Pause	Yellow / YouTube / Repeat		
Pause	Pause / Step / Freeze		
Blue/Sound	Blue / Prime Video / Random		
Stop	Stop / Hold		
Blue/Sound	Sound / Title		