Original		Rechange	
DVD ⏻/I	Power DVD		Power
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
ON SCREEN	On Screen	MEDIA DISPLAY	Display / Media
THEATER POSITION	Theater Position	LIST SMART	Smart / List
ENTER	Enter	OK	OK
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Rechange	
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
ANGLE	Angle	ANGLE INFO	Info / Angle
3D PHONIC	3D Phonic	LANG I/II AUDIO	Audio / Lang I/II
STROBE	Strobe	RDS AV INPUT	AV / Input / RDS
DIGEST	Digest	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Rechange		Original		Rechange	
10	10	GUIDE EPG	Guide / EPG / -/--	7	7 Tv	SHIFT + AUX-HDD 7	Shift + 7
+10	+10	PC FAV MARKER	Fav / Marker / PC	8	8 Tv	SHIFT + USB 8	Shift + 8
OPEN/CLOSE	Open/Close	SURROUND ⏏	Eject / Surround	9	9 Tv	SHIFT + BLUETOOTH 9	Shift + 9
RESUME	Resume	GOTO TEXT	Text / Goto	0	0 Tv	SHIFT + HDMI-SAT 0	Shift + 0
TV ⏻/I	Power Tv	SHIFT + ⏻	Shift + Power	10	10 Tv	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
TV VIDEO	Tv/Video	PROGRAM TV/RADIO	TV/Radio /				
+ TV ch	Tv CH+	+ CH PAGE	CH+ / Page+				
TV ch −	Tv CH-	CH PAGE −	CH- / Page-				
+ TV VOL	Tv Vol +	+ VOL	Vol +				
TV VOL −	Tv Vol -	VOL −	Vol -				
ENTER	Enter Tv	SHIFT + OK	Shift + OK				
1	1 Tv	SHIFT + TV 1	Shift + 1				
2	2 Tv	SHIFT + DVD 2	Shift + 2				
3	3 Tv	SHIFT + CD-STB 3	Shift + 3				
4	4 Tv	SHIFT + VIDEO 4	Shift + 4				
5	5 Tv	SHIFT + TAPE 5	Shift + 5				
6	6 Tv	SHIFT + TUNER 6	Shift + 6				