Mandis shop

VibroShaper VIBROSHAPER

Original		Rechange		Original	Rechange
	Power		Power		
	I >		Play / Slow		
	I >		Pause / Step / Freeze		
	Vel + / Speed+		Up		
	TPO- / Time-		Left		
	TPO+ / Time+		Right		
	Vel - / Speed-		Down		
	M		Menu / Home		
	P		Info / Angle		

https://al-remotes.fr/VibroSpa/1664-359-telecommande-remplacement-pour-VibroSpa-Vibroshaper.html