Mandis shop

Philips CRP763-01

Original		Rechange	
POWER	Power		Power
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
TURBO	Turbo	LIST SMART	Smart / List
BASE	Base	MEDIA DISPLAY	Display / Media
CLOCK	Clock	PROGRAM TV/RADIO	TV/Radio /
TIMER	Timer	TIMER SLEEP	Sleep / Timer
TIME	Time-	CH PAGE −	CH- / Page-
TIME	Time+	+ CH PAGE	CH+ / Page+
MODE	Mode	FORMAT PICTURE	Picture / Format
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down

Original	Rechange

https://al-remotecontrols.fr/Philips/10289524-telecommande-remplacement-pour-Philips-CRP763-01-42259861.htm