Original	Rechange
Power	Power
TV	1
VCR	4
DVD	2
MD	7
TUNER / Band	6
TAPE	5
CD	3
Top Menu	D. Menu / Top
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right
Display	Display / Media
Down	Down
Return	Back / Return

Original	Rechange
I<< / <<	<< / Tune-
I<< / <<	I<< / Preset-
>> / >>I	>> / Tune+
>> / >>I	>>I / Preset+
Stop	Stop / Hold
Play	Play / Slow
Level	Green / APP / Repeat
-	Yellow / YouTube / Repeat
+	Blue / Prime Video / Random
Sound Mode	Sound / Title
SFC	Audio / Lang I/II
Test	Text / Goto
Muting	Mute / Dimmer
Volume-	Vol -
Volume+	Vol +

Original		Rechange	
	Power		Power
	DVD		Smart / List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	-/--/+10		Guide / EPG / -/--
	7		7
	8		8
	9		9
	0		0
	Top Menu		D. Menu / Top
	Up		Up
	Menu		Menu / Home
	Left		Left

Original		Rechange	
	Enter		OK
	Right		Right
	Display		Display / Media
	Down		Down
	Return		Back / Return
	I<< / <<		<< / Tune-
	I<< / <<		I<< / Preset-
	>> / >>I		>> / Tune+
	>> / >>I		>>I / Preset+
	Stop		Stop / Hold
	Play		Play / Slow
	Muting		Mute / Dimmer
	Volume-		Vol -
	Volume+		Vol +

Original	Rechange
Power Tuner - Band	Power
Play	Play / Slow
Stop	Stop / Hold
I <<< / <<	<< / Tune-
>>> / >>I	>> / Tune+
I <<< / <<	I << / Preset -
>>> / >>I	>>I / Preset +
Direct Tuning Tuner - Band	TV/ Radio /
Tuner - Band	Smart / List
MD	Display / Media
1 Tuner - Band	1
2 Tuner - Band	2
3 Tuner - Band	3
4 Tuner - Band	4
5 Tuner - Band	5
6 Tuner - Band	6
7 Tuner - Band	7

Original	Rechange
8 Tuner - Band	8
9 Tuner - Band	9
+10/ - / - -	Guide / EPG / - / - -
0 Tuner - Band	0
Power MD	Shift + Power
Play MD	Shift + Play /
Stop MD	Shift + Stop /
I <<< / << MD	Shift + << /
>>> / >>I MD	Shift + >> /
I <<< / << MD	Shift + I << / Preset -
>>> / >>I MD	Shift + >>I / Preset +
1 MD	Shift + 1
2 MD	Shift + 2
3 MD	Shift + 3
4 MD	Shift + 4
5 MD	Shift + 5
6 MD	Shift + 6

Original	Rechange	Original	Rechange
7 MD	SHIFT + 7 (AUX - HDD)		
8 MD	SHIFT + 8 (USB)		
9 MD	SHIFT + 9 (BLUETOOTH)		
+10/ - / - - MD	SHIFT + GUIDE EPG (-/--)		
0 MD	SHIFT + 0 (HDMI - SAT)		