| Original | | Rechange | |
|---|---|---|---|
| EJECT | Eject | SURROUND | Eject / Surround |
| STANDBY/ON | Standby/On | | Power |
| MENU | Menu | HOME MENU | Menu / Home |
| STATUS/EXIT | Status/Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| CLEAR | Clear | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| 0 | 0 | HDMI - SAT 0 | 0 |
| SYSTEM | System | LIST SMART | Smart / List |

| Original | | Rechange | |
|---|---|---|---|
| RECORD/OTR | Record/OTR | REC MODE | Rec / Rec Mode |
| | Up | | Up |
| | Play | SLOW | Play / Slow |
| STILL | >I</Still | STEP - FREEZE | Pause / Step / Freeze |
| | << | TUNE- | << / Tune- |
| | Left | | Left |
| | Right | | Right |
| | >> | TUNE+ | >> / Tune+ |
| P+ | P+ | CH PAGE | CH+ / Page+ |
| | Stop | HOLD | Stop / Hold |
| | Down | | Down |
| | Vol+ | VOL | Vol+ |
| P– | P- | CH PAGE | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Vol- | VOL | Vol- |
| SV/V+ | Red/SV/V+ | NETFLIX SEARCH | Red / Netflix / Search |
| SMART PICTURE | Green/Smart | APP REPEAT | Green / APP / Repeat |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Green/Smart | Picture / Format | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue/Index | Blue / Prime Video / Random | | |
| [=i] | Info / Angle | | |
| Text | Text / Goto | | |
| [=?] | D.Menu / Top | | |
| [=♦] | Zoom / Size | | |
| [=x] | TV/Radio / | | |
| [=o] | Setup / OPT / | | |
| [=+] | AV / Input / RDS | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |