Mandis shop

Acer MCJ K211007

Original	Rechange	Original	Rechange
Power	Power	2/ Stop/ Back	2
Blue/ 3D	Blue / Prime Video / Random	3/ Play/ Pause/ Ent	3
Yellow/ Source	Yellow / YouTube / Repeat	PgUp/ >>/ >I	>>I / Preset+
Setup/ Media	Setup / OPT /	4/ VGA	4
Green/ Mode	Green / APP / Repeat	5/ Component	5
Hide	TV/ Radio /	6/ Video	6
Zoom	Zoom / Size	PgDn/ S-Video	I << / Preset-
Ratio	Picture / Format	7/ SD/ USB A	7
Freeze	Pause / Step / Freeze	8/ HDMI / MHL	8
Keystone Up	CH+ / Page+	9/ LAN/ WiFi	9
Up	Up	0/ USB B	0
Right	Right		
Left	Left		
Menu	Menu / Home		
Down	Down		
Keystone Down	CH- / Page-		
1/ <</ I <	1		

https://all-remote-controls.nl/fr/Acer/10557-6687-telecommande-de-replacement-pour-Acer-MCJK211007.html