Original		Rechange	
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	Eject / Tv Audio		Eject / Surround
	4		4
	5		5
	6		6
	Recall / Goto		Shift + Text /
	7		7
	8		8
	9		9
	0		0
	Tv Menu		Menu / Home
	Source		AV / Input / RDS
	Up		Up

Original		Rechange	
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	DVD Menu		D.Menu / Top
	Exit		Exit / Cancel / Clear
	Vol +		Vol +
	Sound		Sound / Title
	CH-		CH- / Page-
	Vol -		Vol -
	Pic		Picture / Format
	CH+		CH+ / Page+
	Sleep		Sleep / Timer
	Aspect		Shift + Picture / Format
	DVD Setup		Setup / OPT /
	Back/Tv/Radio		Shift + Back / Return
	Text		Text / Goto

Original		Rechange	
EPG	EPG	GUIDE EPG	Guide / EPG / -/--
EPG	Play	SLOW ▶	Play / Slow
EPG	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
FAV	Stop	HOLD ■	Stop / Hold
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
INFO	Info	ANGLE INFO	Info / Angle
DVD/USB	Red/DVD/USB	NETFLIX SEARCH	Red / Netflix / Search
TITLE	Green/Title	APP REPEAT	Green / APP / Repeat
PBC	Yellow/PBC	YouTube REPEAT A-B	Yellow / YouTube / Repeat
ANGLE	Blue/Angle	Prime Video RANDOM	Blue / Prime Video / Random
<<	<<	TUNE- ◀◀	<< / Tune-
>>	>>	TUNE+ ▶▶	>> / Tune+
I<<	I<<	PRESET- ⏮	I<< / Preset-
>>I	>>I	PRESET+ ⏭	>>I / Preset+
RETURN	Return	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DVD AUDIO	DVD Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
REVEAL	Reveal	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
HOLD	Hold	SHIFT + HOLD ■	Shift + Stop /
LIST	List	LIST SMART	Smart / List
INDEX	Index	PROGRAM TV/RADIO	TV/Radio /
SUBPAGE	Subpage	SHIFT + LIST SMART	Shift + Smart / List
SIZE	Size	SIZE ZOOM	Zoom / Size
MIX	Mix	SHIFT + MEDIA DISPLAY	Shift + Display / Media
FREEZE	Freeze	SHIFT + STEP-FREEZE ⏸	Shift + Pause / Step /