| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CBL/SAT | CBL/SAT | 1 | 1 |
| DVD | DVD | 2 | 2 |
| Blu-ray | Blu-ray | 3 | 3 |
| GAME | Game | 4 | 4 |
| AUX | AUX | 5 | 5 |
| MEDIA PLAYER | Media Player | 6 | 6 |
| iPod/USB | iPod / USB | 7 | 7 |
| CD | CD | 8 | 8 |
| FM | FM | 9 | 9 |
| NETWORK | Network | -/-- GUIDE | Guide |
| TV AUDIO | TV Audio | 0 | 0 |
| INTERNET RADIO | Internet Radio | FAV PRE-CH | Pre Ch |
| FAV 1 | Favorite Station | SHIFT + 1 | Shift + 1 |
| FAVORITE STATION 2 | Favorite Station | SHIFT + 2 | Shift + 2 |
| FAVORITE STATION 3 | Favorite Station | SHIFT + 3 | Shift + 3 |

| Original | | Rechange | |
|---|---|---|---|
| CH/PAGE ▲ | CH + / Page + | + CH | Ch + |
| CH/PAGE ▼ | CH - / Page - | CH – | Ch - |
| MUTE | Mute | MUTE | Mute |
| VOLUME ▲ | Volume + | + VOL | Vol + |
| VOLUME ▼ | Volume - | VOL – | Vol - |
| INFO | Info | DISPLAY INFO | Info |
| OPTION | Option | SETTINGS OPT | Options |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ► | Right | ► | Right |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | Ok |
| BACK | Back | RETURN BACK | Back |
| SETUP | Setup | TOP MENU MENU | Menu |
| TUNE – ⏮ | I<< / Tune - | ⏮ | I<< |
| TUNE – ⏮ | I<< / Tune - | « | << |
| ►/II | Play / Pause | PLAY MODE ► | Play |

| Original | | Rechange | |
|---|---|---|---|
| ►/II | Play / Pause | II | Pause |
| TUNE + ►►I | >>I / Tune + | >>I | >>I |
| TUNE + ►►I | >>I / Tune + | >> | >> |
| MOVIE | Green / Movie | B | Green |
| MUSIC | Red / Music | A | Red |
| GAME | Blue / Game | D | Blue |
| PURE | Yellow / Pure | C | Yellow |

| Original | Rechange |
|---|---|
| | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CBL/SAT | CBL / SAT | 1 | 1 |
| DVD | DVD | 2 | 2 |
| Blu-ray | Blu-ray | 3 | 3 |
| GAME | Game | 4 | 4 |
| AUX | AUX | 5 | 5 |
| MEDIA PLAYER | Media Player | 6 | 6 |
| iPod/USB | iPod / USB | 7 | 7 |
| CD | CD | 8 | 8 |
| FM | FM | 9 | 9 |
| NETWORK | Network | -/-- GUIDE | Guide |
| TV AUDIO | TV Audio | 0 | 0 |
| INTERNET RADIO | Internet Radio | FAV PRE-CH | Pre Ch |
| FAV 1 | Favorite Station | SHIFT + 1 | Shift + 1 |
| FAVORITE STATION 2 | Favorite Station | SHIFT + 2 | Shift + 2 |
| ON 3 | Favorite Station | SHIFT + 3 | Shift + 3 |

| Original | | Rechange | |
|---|---|---|---|
| CH / PAGE ▲ | CH+ / Page + | + CH | Ch + |
| CH / PAGE ▼ | CH - / Page - | CH – | Ch - |
| MUTE | Mute | MUTE | Mute |
| VOLUME ▲ | Volume + | + VOL | Vol + |
| VOLUME ▼ | Volume - | VOL – | Vol - |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |
| ENTER | Enter | OK | Ok |
| BACK | Back | RETURN BACK | Back |
| TUNE – ⏮ | I<< / Tune - | ⏮ | I<< |
| TUNE – ⏮ | I<< / Tune - | « | << |
| ▶/II | Play / Pause | PLAY MODE ▶ | Play |
| ▶/II | Play / Pause | II | Pause |
| TUNE + ⏭ | >>I / Tune + | ⏭ | >>I |
| TUNE + ⏭ | >>I / Tune + | » | >> |