Mandis shop

R- 40A01

Original	Rechange	Original	Rechange
Power	Power	Menu	Menu / Home
1	1	Right / [≡o]	Right
2	2	Vol +	Vol +
3	3	Down	Down
4	4	PR-	CH- / Page-
5	5	Sleep/ [≡♦]	Sleep / Timer
6	6	Mute	Mute / Dimmer
7	7	Recall / [≡?]	Back / Return
8	8	Red/ Skip	Red / Netflix / Search
9	9	Green/ Movie	Green / APP / Repeat
Source/ [≡]	AV / Input / RDS	[≡x]	Exit / Cancel / Clear
0	0	Yellow/ Delete	Yellow / YouTube / Repeat
Normal / OK/ [≡i]	OK	Blue/ Mode	Blue / Prime Video / Random
PR+	CH+ / Page+	[≡]	Text / Goto
Up	Up		
Vol -	Vol -		
Left / [≡+]	Left		

https://all-remote-controls.nl/fr/10103-2379-telecommande-de-replacement-pour-R-40A15-8B7-8A01.html