Original	Rechange	Original	Rechange
AVR Power On	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Back/Exit	Exit / Cancel / Clear
Pause	Pause / Step / Freeze	Down	Down
Stop	Stop / Hold	Last	Back / Return
<<	<< / Tune-	Vol +	Vol +
>>	>> / Tune+	AVR	Smart / List
I<<	I<< / Preset-	CH/Page Up	CH+ / Page+
>>I	>>I / Preset+	Vol -	Vol -
Audio Effects	Audio / Lang I/II	CH/Page Down	CH- / Page-
Surround Modes	Eject / Surround	1	1
Video Modes	Picture / Format	2	2
Sleep	Sleep / Timer	3	3
Menu	Menu / Home	4	4
Up	Up	5	5
Info	Info / Angle	6	6
Left	Left	7	7

Original	Rechange	Original	Rechange
8	USB 8 — 8	Cable/ Sat	SHIFT + HDMI - SAT 0 — Shift + 0
9	BLUETOOTH 9 — 9		
0	HDMI - SAT 0 — 0		
Red	NETFLIX SEARCH — Red / Netflix / Search		
Green	APP REPEAT — Green / APP / Repeat		
Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM — Blue / Prime Video / Random		
AVR Power Off	SHIFT + Power — Shift + Power		
Tv	SHIFT + TV 1 — Shift + 1		
Blu-ray	SHIFT + DVD 2 — Shift + 2		
DVR	SHIFT + CD - STB 3 — Shift + 3		
iPod	SHIFT + VIDEO 4 — Shift + 4		
Network	SHIFT + TAPE 5 — Shift + 5		
Radio	SHIFT + TUNER 6 — Shift + 6		
AUX	SHIFT + AUX - HDD 7 — Shift + 7		
Game	SHIFT + USB 8 — Shift + 8		
Media Server	SHIFT + BLUETOOTH 9 — Shift + 9		

Original	Rechange	Original	Rechange
1	1	Mute	Mute / Dimmer
DVR	Display / Media	Vol +	Vol +
DVR Power On	Power	Vol -	Vol -
2	2	CH/Page Up	CH+ / Page+
3	3	CH/Page Down	CH- / Page-
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Menu	Menu / Home		
Up	Up		
Down	Down		
Right	Right		
Left	Left		

Original	Rechange	Original	Rechange
Bluray Power	Power	Down	Down
Mute	Mute / Dimmer	Last	Back / Return
Play	Play / Slow	Vol +	Vol +
Pause	Pause / Step / Freeze	Vol -	Vol -
Stop	Stop / Hold	Blu-ray	Display / Media
Rec	Rec / Rec Mode	1	1
<<	<< / Tune-	2	2
>>	>> / Tune+	3	3
I<<	I<< / Preset-	4	4
>>I	>>I / Preset+	5	5
Disc Menu	D.Menu / Top	6	6
Menu	Menu / Home	7	7
Up	Up	8	8
Left	Left	9	9
OK	OK	0	0
Right	Right	Red	Red / Netflix / Search
Back/Exit	Exit / Cancel / Clear	Green	Green / APP / Repeat

Original	Rechange	Original	Rechange
Yellow	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM — Blue / Prime Video / Random		
Bluray Power Off	SHIFT + Power — Shift + Power		

Original		Rechange	
AVR Power On		Power	
AVR Power Off		SHIFT +	Shift + Power
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Menu		Menu / Home	
Back/Exit		Exit / Cancel / Clear	
Last		Back / Return	
Up		Up	
Down		Down	

Original		Rechange	
Right		Right	
Left		Left	
OK		OK	
Red		Red / Netflix / Search	
Green		Green / APP / Repeat	
Yellow		Yellow / YouTube / Repeat	
Blue		Blue / Prime Video / Random	
Vol +		Vol +	
Vol -		Vol -	
Mute		Mute / Dimmer	
CH/Page Up		CH+ / Page+	
CH/Page Down		CH- / Page-	
Pause		Pause / Step / Freeze	
I<<		I<< / Preset-	
>>I		>>I / Preset+	
Play		Play / Slow	
<<		<< / Tune-	

Original		Rechange	
	>>	TUNE+	>> / Tune+
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
INFO	Info	ANGLE INFO	Info / Angle
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AVR	AVR	LIST SMART	Smart / List
Audio Effects	Audio Effects	LANG I/II AUDIO	Audio / Lang I/II
Video Modes	Video Modes	FORMAT PICTURE	Picture / Format
Surround Modes	Surround Modes	SURROUND	Eject / Surround
Cable/ Sat	Cable/ SAT	SHIFT + HDMI - SAT 0	Shift + 0
Blu-ray	Blu-ray	SHIFT + DVD 2	Shift + 2
iPod	iPod	SHIFT + VIDEO 4	Shift + 4
Radio	Radio	SHIFT + TUNER 6	Shift + 6
TV	TV	SHIFT + TV 1	Shift + 1
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
DVR	DVR	SHIFT + CD - STB 3	Shift + 3
Game	Game	SHIFT + USB 8	Shift + 8

Original		Rechange	
Media Server	Media Server	SHIFT + BLUETOOTH 9	Shift + 9
Network	Network	SHIFT + TAPE 5	Shift + 5